


WorkVisual 2.4

For KUKA System Software 8.1 and 8.2

For VW System Software 8.1 and 8.2



Issued: 29.03.2012

Version: KST WorkVisual 2.4 V3 en

© Copyright 2012

KUKA Roboter GmbH
Zugspitzstraße 140
D-86165 Augsburg
Germany

This documentation or excerpts therefrom may not be reproduced or disclosed to third parties without the express permission of KUKA Roboter GmbH.

Other functions not described in this documentation may be operable in the controller. The user has no claims to these functions, however, in the case of a replacement or service work.

We have checked the content of this documentation for conformity with the hardware and software described. Nevertheless, discrepancies cannot be precluded, for which reason we are not able to guarantee total conformity. The information in this documentation is checked on a regular basis, however, and necessary corrections will be incorporated in the subsequent edition.

Subject to technical alterations without an effect on the function.

Translation of the original documentation

KIM-PS5-DOC

Publication:	Pub KST WorkVisual 2.4 (PDF) en
Bookstructure:	KST WorkVisual 2.4 V1.3
Version:	KST WorkVisual 2.4 V3 en

Contents

1	Introduction	7
1.1	Target group	7
1.2	Representation of warnings and notes	7
1.3	Trademarks	7
1.4	Licenses	7
1.5	Terms used	8
2	Product description	9
3	Safety	11
4	Installation	13
4.1	PC system requirements	13
4.2	System requirements, robot controller	13
4.3	Installing WorkVisual	13
4.4	Uninstalling WorkVisual	14
5	Graphical user interface	15
5.1	Overview of the graphical user interface	15
5.2	Displaying/hiding windows	16
5.3	Repositioning the windows	16
5.4	Displaying different views of the user interface	18
5.5	Displaying/hiding buttons	18
5.6	Button bar	19
5.7	Messages window	21
5.8	Project structure window	21
5.9	Resetting the graphical user interface	21
6	Operation	23
6.1	Starting WorkVisual	23
6.2	Opening a project	23
6.3	Creating a new project	24
6.3.1	Creating a new empty project	24
6.3.2	Creating a project with a template	24
6.3.3	Creating a project on the basis of an existing project	24
6.4	Saving project information	24
6.5	Saving the project	25
6.6	Closing the project	25
6.7	Closing WorkVisual	25
6.8	Importing device description files	25
6.9	Inserting the field bus master in the DTM Catalog (Catalog Scan)	26
6.10	Inserting a catalog in a project	26
6.11	Removing a catalog from the project	27
6.12	Inserting a robot controller in a project	27
6.13	Setting the robot controller to active/inactive	27
6.14	Changing the values " Firmware version " and/or " Number of I/Os "	28
6.15	Removing a robot controller from a project	28
6.16	Assigning a robot to the robot controller	28
6.17	Adding an external axis	29

6.18	Option packages	30
6.18.1	Installing an option package in WorkVisual	30
6.18.2	Updating an option package	31
6.18.3	Uninstalling an option package	31
6.18.4	Inserting the catalog of the option package into the project	32
6.18.5	Removing the catalog of the option package from the project	32
6.18.6	Inserting an option package in a project	32
6.18.7	Removing an option package from the project	33
6.18.8	Adding a device from an option package to the robot controller	33
6.18.9	Exporting a subproject	34
6.19	Changing predefined properties of WorkVisual	34
6.19.1	Overview	34
6.19.2	Configuring booting and saving characteristics	35
6.19.3	Configuring keyboard shortcuts	35
6.19.4	Changing the user interface language	36
6.20	Print functions	36
7	Safety configuration	39
7.1	Safety configuration in WorkVisual	39
7.2	Editing the local safety configuration	39
7.3	“General” tab	40
7.4	Importing machine data into the local safety configuration	40
7.5	Importing a local safety configuration	41
7.6	Exporting a local safety configuration	41
7.7	Importing safety zones	42
8	Bus configuration	45
8.1	Configuring the bus	45
8.1.1	Overview: Bus configuration	45
8.1.2	Inserting a field bus master in a project	45
8.1.3	Configuring the field bus master	46
8.1.4	Inserting devices manually into the bus	46
8.1.5	Configuring devices	46
8.1.6	Importing a PROFINET configuration	47
8.1.6.1	Differences between the PROFINET configuration and the project	47
8.1.7	Automatically inserting devices into the bus (Bus Scan)	49
8.2	Editing field bus signals	50
8.2.1	Signal Editor	50
8.2.2	Changing the bit width of signals	52
8.2.3	Swapping signals (reversing the byte order)	52
8.2.4	Changing the data type	54
8.2.5	Changing signal names	54
8.3	Mapping the bus I/Os	55
8.3.1	I/O Mapping window	55
8.3.2	Buttons in the I/O Mapping window	56
8.3.3	Mapping input to output	57
8.3.4	Mapping bus input to bus output	58
8.3.5	Multiple mapping or reverse mapping of signals	58
8.3.6	Searching for assigned signals	59

8.3.7	Grouping signals	60
8.3.8	Editing analog KRC signals	60
8.4	Exporting the bus configuration	61
9	Long texts	63
9.1	Displaying / editing long texts	63
9.2	Importing long texts	63
9.3	Exporting long texts	64
10	Configuring the controller bus, extension bus, system bus	67
10.1	Overview	67
10.2	Importing device description files (EtherCAT ESI)	67
10.3	Configuring the controller bus	68
10.3.1	Inserting (or removing) devices on the controller bus	68
10.3.2	Checking the device settings	69
10.3.3	Connecting devices on the controller bus	70
10.3.4	“Topology” tab	71
10.3.5	Inserting the wagon driver configuration	72
10.4	Controller bus configuration for KUKA.ServoGun FC	73
10.5	Configuring further buses	73
11	RoboTeam	75
11.1	Creating a RoboTeam	75
11.1.1	Creating a new RoboTeam project	75
11.1.2	Inserting a RoboTeam in an existing project	76
11.2	Configuring the RoboTeam	77
11.2.1	Editors for the robot network and RoboTeam	77
11.2.2	Linking RoboTeams to form a single safety circuit	78
11.2.3	Defining the time master	79
11.2.4	Defining the motion master	80
11.2.5	Deleting a master/slave link	81
11.2.6	Creating and configuring workspaces	82
11.3	Preventing data loss in RoboTeam projects	83
11.4	Transferring a RoboTeam project to the robot controller	84
12	Programming	87
12.1	Creating a program	87
12.2	Importing a program	87
12.3	Displaying the variable declarations in a file	87
12.4	KRL Editor	89
12.4.1	Opening a file in the KRL Editor	89
12.4.2	KRL Editor user interface	90
12.4.3	Zooming in/out	90
12.4.4	Configuring the KRL Editor	91
12.4.5	Edit functions	91
12.4.5.1	General edit functions	91
12.4.5.2	Renaming variables	92
12.4.5.3	Auto-complete	92
12.4.5.4	Snippets – Fast entry of KRL instructions	93
12.4.6	Folds	94

12.4.7	Jumping to the declaration of a variable	94
12.4.8	Quickfix correction	94
12.4.8.1	Correcting or automatically declaring undeclared variables	95
12.4.8.2	Removing unused variables	95
12.4.8.3	Standardizing the upper/lower case in a variable name	96
12.4.9	Creating user-specific snippets	96
13	Transferring and activating the project	101
13.1	Generating code	101
13.2	Pinning a project	101
13.3	Assigning the robot controller to the real robot controller	102
13.4	Transferring the project to the robot controller	104
13.5	Activating a project	108
13.5.1	Activating a project (in WorkVisual)	108
13.6	Checking the safety configuration of the robot controller	110
13.7	Transferring a project from the robot controller to WorkVisual	110
13.8	Comparing projects (and accepting differences)	110
14	Diagnosis	115
14.1	Trace	115
14.1.1	Configuring and starting the trace recording	115
14.1.2	Importing a trace configuration	115
14.1.3	Exporting a trace configuration	116
14.1.4	“Trace configuration” window	116
14.1.4.1	“General” tab	116
14.1.4.2	“Trigger” tab	118
14.1.4.3	“I/O” tab	119
14.1.4.4	“Channels” tab	120
14.1.5	Importing a trace recording	121
14.1.6	Displaying a trace recording	121
14.1.7	“Trace Analysis” window	122
14.1.7.1	“Channels” tab	122
14.1.7.2	“Oscilloscope” tab	123
14.1.8	Panning and zooming the oscilloscope display	124
14.1.9	Creating a screenshot of the oscilloscope display	125
14.2	Displaying diagnostic data about the robot controller	125
14.3	Displaying online system information	127
15	KUKA Service	131
15.1	Requesting support	131
15.2	KUKA Customer Support	131
	Index	139

1 Introduction

1.1 Target group

This documentation is aimed at users with the following knowledge and skills:

- Advanced knowledge of the robot controller system
- Advanced knowledge of bus technologies



For optimal use of our products, we recommend that our customers take part in a course of training at KUKA College. Information about the training program can be found at www.kuka.com or can be obtained directly from our subsidiaries.

1.2 Representation of warnings and notes

Safety

These warnings are relevant to safety and **must** be observed.



These warnings mean that it is certain or highly probable that death or severe physical injury **will** occur, if no precautions are taken.



These warnings mean that death or severe physical injury **may** occur, if no precautions are taken.



These warnings mean that minor physical injuries **may** occur, if no precautions are taken.



These warnings mean that damage to property **may** occur, if no precautions are taken.



These warnings contain references to safety-relevant information or general safety measures. These warnings do not refer to individual hazards or individual precautionary measures.

Notes

These hints serve to make your work easier or contain references to further information.



Tip to make your work easier or reference to further information.

1.3 Trademarks

Windows is a trademark of Microsoft Corporation.

Pentium is a trademark of Intel Corporation.

Step 7 are trademarks of Siemens AG.

PC WORX is a trademark of Phoenix Contact.

1.4 Licenses

This KUKA software product uses open-source software. The licensing terms are displayed during installation of the KUKA software product.

1.5 Terms used

Term	Description
DTM	Device Type Manager
KCP	KUKA Control Panel General name for KUKA teach pendants
KRL	KUKA Robot Language
KSS	KUKA System Software
KUKA smartHMI	Name of the graphical user interface for the (V)KR C4 robot controller
KUKA smartPAD	Name of the KCP for the (V)KR C4 robot controller

2 Product description

The **WorkVisual** software package is the engineering environment for KR C4 controlled robotic cells. It offers the following functionalities:

- Configuring and connecting field buses
- Programming robots offline
- Configuring RoboTeams offline
- Editing the safety configuration
- Transferring projects to the robot controller
- Transferring projects from the robot controller to WorkVisual
- Comparing a project with another project and accepting differences where necessary
- Managing long texts
- Managing option packages
- Diagnostic functionality
- Online display of system information about the robot controller
- Configuring traces, starting recordings, evaluating traces (with the oscilloscope)




Fig. 2-1: WorkVisual graphical user interface

3 Safety

This documentation contains safety instructions which refer specifically to the software described here. The fundamental safety information for the industrial robot can be found in the "Safety" chapter of the Operating and Programming Instructions for System Integrators or the Operating and Programming Instructions for End Users.



The "Safety" chapter in the operating and programming instructions must be observed. Death to persons, severe physical injuries or considerable damage to property may otherwise result.



WARNING WorkVisual can be used with write access to modify outputs in the robot controller, without this being noticed by any persons located inside the system. In the test modes, such access is not permitted. Outputs of the robot controller must not be modified using WorkVisual ("Single Point of Control" principle)! Death to persons, severe physical injuries or considerable damage to property may otherwise result.



WARNING WorkVisual can be used with write access to modify programs, I/O assignments, signal declarations and other parameters in the robot controller. The following applies here: New or modified programs must always be tested first in Manual Reduced Velocity mode (T1). After modifications to the industrial robot, existing programs must always be tested first in Manual Reduced Velocity mode (T1). This applies to all components of the industrial robot and includes modifications to the software and configuration settings. In particular, this also applies when a WorkVisual project has been activated on the robot controller.



WARNING After importing a safety configuration or parts thereof, the safety configuration must be checked! If this is not done, this can lead to the possibility of the robot being operated with incorrect data when the project is transferred to the real robot controller. Death to persons, severe physical injuries or considerable damage to property may result.



WARNING When activating a project on the KUKA smartHMI, an overview is displayed of the changes which will be made in comparison to the project that is still active on the robot controller. If changes are listed in the overview under the heading **Safety-relevant communication parameters**, this means that the behavior of the Emergency Stop and "Operator safety" signal may have changed compared with the previous project. After activation of the project, the Emergency Stop and the "Operator safety" signal must be checked for safe functioning. If the project is activated on several robot controllers, this check must be carried out for every robot controller. Failure to carry out this check may result in death to persons, severe physical injuries or considerable damage to property.



WARNING After activation of a project on the robot controller, the safety configuration must be checked there! If this is not done, the robot will possibly be operated with incorrect data. Death to persons, severe physical injuries or considerable damage to property may result.

(>>> 13.6 "Checking the safety configuration of the robot controller"
Page 110)



If the activation of a project fails, an error message is displayed in WorkVisual. In this case, one of the following measures must be carried out:

- Either: Activate a project again (the same one or a different one).
- Or: Reboot the robot controller with a cold restart.

4 Installation

4.1 PC system requirements

Hardware	<p>Minimum requirements</p> <ul style="list-style-type: none"> ■ PC with Pentium IV processor, min. 1500 MHz ■ 512 MB RAM ■ DirectX8-compatible graphics card with a resolution of 1024x768 pixels <p>Recommended specifications</p> <ul style="list-style-type: none"> ■ PC with Pentium IV processor and 2500 MHz ■ 1 GB RAM ■ DirectX8-compatible graphics card with a resolution of 1280x1024 pixels
Software	<ul style="list-style-type: none"> ■ Windows XP incl. Service Pack 2.0 Or Windows 7 ■ If Multiprog is to be interfaced with WorkVisual: <ul style="list-style-type: none"> ■ KUKA.PLC Multiprog 5-35 4.0 must be installed. ■ Multiprog must be licensed.

4.2 System requirements, robot controller

Software	<ul style="list-style-type: none"> ■ KUKA System Software 8.1 or 8.2 ■ Or VW System Software 8.1 or 8.2
-----------------	---

4.3 Installing WorkVisual

Precondition	<ul style="list-style-type: none"> ■ Local administrator rights
---------------------	--

Procedure	<ol style="list-style-type: none"> 1. Start the program setup.exe. 2. If the following components are not yet installed on the PC, an installation wizard opens: <ul style="list-style-type: none"> ■ .NET Framework 2.0, 3.0 and 3.5 <p>Follow the instructions in the installation wizard. .NET Framework is installed.</p> 3. If the following component is not yet installed on the PC, an installation wizard opens: <ul style="list-style-type: none"> ■ SQL Server Compact 3.5 <p>Follow the instructions in the installation wizard. SQL Server Compact 3.5 is installed.</p> 4. If the following components are not yet installed on the PC, an installation wizard opens: <ul style="list-style-type: none"> ■ Visual C++ Runtime Libraries ■ WinPcap <p>Follow the instructions in the installation wizard. Visual C++ Runtime Libraries and/or WinPcap is installed.</p> 5. The WorkVisual [...] Setup window opens. Click on Next. 6. Accept the license agreement and click on Next. 7. Select the directory and click on Next. 8. Click Install. WorkVisual is installed. 9. Once installation is completed, click on Finish to close the installation wizard.
------------------	--

4.4 Uninstalling WorkVisual



It is advisable to archive all relevant data before uninstalling a software package.

Precondition

- Local administrator rights
- The setting **Show hidden files and folders** is activated in Windows Explorer.

Procedure

1. In the Windows Start menu, select **Settings > Control Panel > Software**, and delete the entry **WorkVisual [...]**.



Steps 2-6 are only necessary if the entire user configuration is to be deleted.

2. In the directory C:\Program Files\KUKA, delete the folder **WorkVisual [...]**.
3. In the directory C:\Documents and Settings*Username*\Application Data\KUKA Roboter GmbH, delete the folder **WorkVisual**.
4. In the directory C:\Documents and Settings\All Users\Application Data\KUKA Roboter GmbH, delete the folder **WorkVisual**.
5. Delete the **WorkVisual Projects** folder in the **My Documents** directory.
6. In the directory C:\Documents and Settings\All Users\Application Data\KUKA Roboter GmbH, delete the folder **DeviceDescriptions**.

5 Graphical user interface

5.1 Overview of the graphical user interface

Not all elements on the graphical user interface are visible by default, but they can be shown or hidden as required.

There are other windows and editors available in addition to those shown here. These can be displayed via the **Window** and **Editors** menus.




Fig. 5-1: Overview of the graphical user interface

Item	Description
1	Menu bar
2	Button bars (>>> 5.5 "Displaying/hiding buttons" Page 18) (>>> 5.6 "Button bar" Page 19)
3	Editor area If an editor is open, it is displayed here. More than one editor can be open simultaneously – as shown here in the example. In this case, they are stacked one on top of the other and can be selected via tabs.
4	Help button
5	Project structure window

Item	Description
6	Catalogs window All catalogs added are displayed in this window. The elements in the catalogs can be inserted by Drag&Drop on the Hardware or Geometry tabs in the Project structure window.
7	Workspace Selection window (>>> 5.4 "Displaying different views of the user interface" Page 18)
8	Messages window (>>> 5.7 "Messages window" Page 21)
9	Properties window If an object is selected, its properties are displayed in this window. The properties can be changed. Individual properties in gray boxes cannot be changed.

5.2 Displaying/hiding windows

Procedure

1. Select the menu item **Window**. A list of available windows opens.
2. Click on a window in the list in order to display or hide it on the graphical user interface.

5.3 Repositioning the windows

Precondition

- The desired window is displayed on the graphical user interface.

Procedure

Free positioning of windows:

1. Right-click in the title bar of the window. A context menu is opened.
2. Select the option **Floating**.
3. Grip the window by the title bar and move it to the desired position on the graphical user interface.

If the mouse pointer is positioned over the edges or corners of the window, arrows appear which can be dragged to make the window larger or smaller.

Fixed positioning of windows:

1. Right-click in the title bar of the window. A context menu is opened.
2. Select the option **Dockable**.
3. Grip the window by the title bar and move it to the desired position on the graphical user interface.
 - Anchor points are displayed at the right, left, top and bottom of the user interface.
 - If the window is moved over another fixed window, an anchor cross is displayed.
(>>> "Anchor cross" Page 17)
4. Drag the window onto an anchor point or the cross. The window is now anchored.

Automatic hiding and displaying of anchored windows:

1. Right-click in the title bar of the window. A context menu is opened.
2. Select the option **Auto-Hide**. The window is hidden. A tab with the name of the window remains at the edge of the user interface.
3. To show the window again, move the mouse pointer over the tab.

- To hide the window again, move the mouse pointer off the window. If necessary, click on an area outside the window.

The **Auto-Hide** option creates more space for working in other areas of the user interface. Nonetheless, the window can still be quickly shown again at any time.

There is a pin symbol in the title bar of the window.

- Alternatively, **Auto-Hide** can also be activated or deactivated by clicking on this pin symbol.




Fig. 5-2: Pin symbol

Anchor cross

If a window is moved over another fixed window, an anchor cross is displayed.




Fig. 5-3: Anchor cross

Depending on which side of the anchor cross the window is dragged, it is then anchored on this side of the previously window.

If the window is dragged over to the center of the anchor cross, both windows are anchored one on top of the other. Tabs are displayed underneath the windows, making it possible to switch between windows.




Fig. 5-4: Windows anchored on top of each other

To move windows that are anchored one on top of the other:

- Dragging on a tab moves only the corresponding window.
- Dragging on the title bar moves the whole stack of windows.

5.4 Displaying different views of the user interface

Description

The WorkVisual user interface can be displayed in 2 different views. These can be selected via the menu item **View** or via the **Workspace Selection** window.

The views are tailored to different types of work:

View	Focus
Programming and configuration	Area for project-related work For example: cell configuration, I/O mapping and work with the KRL Editor.
Online administration	Area for project-independent work e.g. monitoring, recording The functions in this view are only available when there is no project opened.

Each view can be adapted separately to the needs of the user. Examples:

- Position the button bars differently in each view.
- Hide the message window in one view and not in another.

Procedure

Show the **Workspace Selection** window:

- Select the menu sequence **Window > Workspace Selection**.




Fig. 5-5: Workspace Selection window

To reset the current view to the default settings:

- Select the menu sequence **Window > Reset active workspace**.

To reset the all views to the default settings:

- Select the menu sequence **Window > Reset all workspaces**.

5.5 Displaying/hiding buttons

Description

The individual buttons can be added or removed. In this way, the button bar can be tailored to the needs of the user.

Procedure

1. Click on the arrow on the right of the button bar.



Fig. 5-6: Example: File button bar: Click on the arrow on the right

2. The menu item **Add or Remove Buttons** is displayed. Click on this, and then on the submenu item [*BarName*].

3. An overview of all the buttons in this bar is displayed. Click on a button in the overview in order to add or remove it.




Fig. 5-7: Example: File button bar: Overview

5.6 Button bar

Button	Name / description
	New... Opens a new, empty project.
	Open project Opens the Project Explorer .
	Save project Saves the project.
	Cut Deletes the selected element from its original position and copies it to the clipboard.
	Copy Copies the selected element to the clipboard.
	Paste Inserts the cut or copied element at the selected position.
	Delete Deletes the selected element.
	Opens the Add Point dialog. Opens a window in which an element can be selected and added to the tree structure. The elements offered depend on the element that is selected in the tree structure. Example: If a robot controller is selected in the tree structure, elements such as robots and external axes are offered in the window for adding. The button is only active if an element is selected on the Hardware or Files tab of the Project structure window.
	Set as active controller / Reset active controller Sets a robot controller to active/inactive.

Button	Name / description
	Undo Undo the last action.
	Redo Redoes the action that was undone.
	Settings... Opens a window with the hardware data. The button is only active if a device is selected on the Hardware tab of the Project structure window.
	Connect with device Establishes a connection with a field bus device. The button is only active if the field bus master is selected on the Hardware tab of the Project structure window.
	Disconnect from device Terminates the connection with a field bus device.
	Scan Topology... Scans a bus.
	Abort last action Cancels certain actions, e.g. a bus scan. The button is only active if a cancelable action is running.
	Monitor Currently without function.
	Diagnosis... Currently without function.
	Deploy... Transfers the project to the robot controller.
	Generate code (>>> 13.1 "Generating code" Page 101)
	Opens the I/O Mapping Editor Opens the I/O Mapping window.
	The local safety configuration of the controller Opens the local safety configuration of the current robot controller.
	KRL Editor Opens the current file in the KRL Editor. The button is only active if a file is selected on the Files tab of the Project structure window which can be opened with the KRL Editor.
	Symbol Table Editor Opens the Symbol Table Editor window.
	Help Opens the Help.

Only in the **Online administration** workspace:

Button	Name / description
	Opens an editor for online system information
	Diagnostic monitor Displays the Diagnostic monitor window. The button is only active in the Diagnosis view.
	Opens the Trace Configuration Editor. Opens the Trace configuration window.
	Opens the trace analysis editor (oscilloscope). Opens the Trace Analysis window.

5.7 Messages window

Description Messages are displayed here. The following options can be set in the message window:

Language:

The desired language can be selected here.

Category:

- **Message history:** Displays all messages except errors relating to KRL code.
Messages are not automatically deleted, even if they refer to a temporary state that is no longer active. Messages can be deleted by right-clicking on them and selecting the option **Delete all**.
- **KRL Parser:** Display of errors in the KRL code of the file currently open in the **KRL Editor** window.

5.8 Project structure window

The **Project structure** window contains the following tabs:

Hardware The **Hardware** tab shows the relationship between the various devices. Here, the individual devices can be assigned to a robot controller.

Geometry The **Geometry** tab displays all the geometrical objects used in the project in a tree structure (kinematic systems, tools, base objects). The properties of the objects can be edited.

If objects need to be linked geometrically, e.g. if a robot is to be assigned to a KUKA linear unit: this must be done here on the **Geometry** tab (Drag&Drop).

Files The **Files** tab contains the program and configuration files belonging to the project.

Coloring of file names:

- Files generated automatically (with **Generate code** function): gray
- Files inserted manually in WorkVisual: blue
- Files transferred to WorkVisual from the robot controller: black

5.9 Resetting the graphical user interface

Description All the settings affecting the graphical user interface and its behavior that the user has made in WorkVisual can be reset to the default state (as after installation).

This includes changes to the button bars, windows that have been displayed or hidden, and settings made in the **Options** window.

Procedure

1. Select the menu sequence **Window > Reset configuration**.
2. Close WorkVisual and restart it.

6 Operation

6.1 Starting WorkVisual

- Procedure**
1. Double-click on the WorkVisual icon on the desktop.
 2. When WorkVisual is started for the first time, the DTM Catalog Management is opened. Here a catalog scan must be carried out.
(>>> 6.9 "Inserting the field bus master in the DTM Catalog (Catalog Scan)" Page 26)

6.2 Opening a project

Description This procedure is used to open a project.

Projects can also be opened from older versions of WorkVisual. WorkVisual creates a backup copy of the older project and then converts the project. Before this happens, a dialog is displayed requesting the user to confirm the conversion.

- Procedure**
1. Select the menu sequence **File > Open project**.
Or: Click on the **Open project** button.
 2. The **Project Explorer** is opened. On the left, the **Open project** tab is selected. A list of projects is displayed.
Select a project and click on **Open**. The project is opened.
 3. Set the robot controller as the active controller.




Fig. 6-1: Project Explorer

- Alternative procedure**
1. Select the menu sequence **File > Recent projects**. A submenu containing recently opened projects is opened.
 2. Select a project. The project is opened.
 3. Set the robot controller as the active controller.

Projects which are located on a robot controller and have not yet been saved on this PC can also be transferred to WorkVisual and opened there. To do this, a different procedure must be used:

(>>> 13.7 "Transferring a project from the robot controller to WorkVisual" Page 110)

6.3 Creating a new project

6.3.1 Creating a new empty project

- Procedure**
1. Click on the **New...** button. The **Project Explorer** is opened. On the left, the **Create project** tab is selected.
 2. Select the **Blank project** template.
 3. Enter a name for the project in the **File name** box.
 4. The default directory for projects is given in the **Location** box. If required, select a different directory.
 5. Click on the **New** button. A new, empty project is opened.

6.3.2 Creating a project with a template

- Procedure**
1. Click on the **New...** button. The **Project Explorer** is opened. On the left, the **Create project** tab is selected.
 2. Select the desired template in the **Available templates** area of the tab.
 3. Enter a name for the project in the **File name** box.
 4. The default directory for projects is given in the **Location** box. If required, select a different directory.
 5. Click on the **New** button. The new project is opened.

Templates The templates available for selection include:

Template	Description
Blank project	Blank project
KR C4 project	This project contains a KR C4 controller and the catalog KRL Templates .
VKR C4 project	This project contains a VKR C4 controller and the catalog VW Templates .

6.3.3 Creating a project on the basis of an existing project

- Procedure**
1. Click on the **New...** button. The **Project Explorer** is opened. On the left, the **Create project** tab is selected.
 2. Select the desired project in the **Available projects** area of the tab.
 3. Enter a name for the new project in the **File name** box.
 4. The default directory for projects is given in the **Location** box. If required, select a different directory.
 5. Click on the **New** button. The new project is opened.

6.4 Saving project information

Description If required, the user can assign information to the project. The following information can be saved:

- A description
- A preview image (screenshot)

The following information is saved and displayed by default:

- The version
- The creation date and change date
- The current file location
- The project ID

- Precondition** ■ A project is open.
- Procedure**
1. Select the menu sequence **Extras > Project info**. The window **Project info for ...** is opened.
 2. Enter a description in the **Description** box (optional).
 3. Click on the **Insert image from file** button (optional). Select an image and confirm with **Open**.
 4. Click on **OK**. The window **Project info for ...** is closed and the project information is saved.

6.5 Saving the project

Description Projects have the file format WVS ("WorkVisual Solution").

A project can be saved with one of the following functions:

- **Save**: Saves the open project.
- **Save as**: This function is used to save a copy of the open project. The open project itself is closed and remains unchanged.

Procedure for Save ■ Select the menu sequence **File > Save**.
Or click on the **Save project** button.

Procedure for Save as

1. Select the menu sequence **File > Save as**.
The **Save as** window is opened. A file location for the project can be selected here.
2. Enter a name in the **File name** box and click on the **Save** button.

6.6 Closing the project


Procedure ■ Select the menu sequence **File > Close**.
If changes have been made, a request for confirmation is displayed, asking if the project should be saved.

6.7 Closing WorkVisual

Procedure ■ Select the menu sequence **File > Exit**.
If a project is open, a request for confirmation is displayed, asking if the project should be saved.

6.8 Importing device description files

Description To be able to use a device in WorkVisual, WorkVisual requires the device description file for this device.



Precondition ■ There is no project open.

Procedure

1. Select the menu sequence **File > Import / Export**. The **Import/Export Wizard** window is opened.
2. Select **Import device description file** and click on **Next >**.
3. Click on **Browse...** and navigate to the directory where the files are located. Confirm with **Next >**.
4. A window opens. Select the desired robot type in the **File type** box.

5. Select the file to be imported and confirm with **Open**.
6. Click on **Finish**.
7. Close the **Import/Export Wizard** window.

6.9 Inserting the field bus master in the DTM Catalog (Catalog Scan)

Description This procedure only needs to be carried out when WorkVisual is started for the first time after installation.

- Procedure**
1. The **DTM Catalog Management** window opens automatically.
If necessary, it can also be opened via the menu sequence **Extras > DTM Catalog Management...**
 2. Click on **Search for installed DTMs**. WorkVisual searches the PC for relevant files. The search results are displayed.
 3. Under **Known DTMs**, select the required files and click on the **Right arrow** button.
If all files are to be accepted, click on the **Double right arrow** button.
 4. The selected files are displayed under **Current DTM Catalog**. Click on **OK**.




Fig. 6-2: DTM Catalog Management

6.10 Inserting a catalog in a project

Description The catalogs contain all the elements that are required to generate programs. In order to be able to use a catalog, it must first be inserted in the project.

The following catalogs are available by default in WorkVisual:

Catalog	Description
DtmCatalog	Device description files
KRL Templates	Templates for KRL programs
KukaControllers	Robot controllers
KukaExternalAxis	External axes
KukaMisc	Demonstration workpieces
KukaRobotsKRC4 [...]	Several catalogs with robot models for KR C4

Catalog	Description
KukaSpecialRobots	Special robot models
VW Templates	Templates for VW programs

- Procedure**
1. Select the menu sequence **File > Catalog management...**. A window opens.
 2. Double-click on the desired catalog in the **Available catalogs** area. The catalog is now displayed in the **Project catalogs** area.
 3. Close the window.
The catalog has been inserted in the project. It is now available in the **Catalogs** window.

6.11 Removing a catalog from the project

- Procedure**
1. Select the menu sequence **File > Catalog management...**. A window opens.
 2. Double-click on the catalog to be removed in the **Project catalogs** area. The catalog is now displayed in the **Available catalogs** area.
 3. Close the window.

6.12 Inserting a robot controller in a project

Description One or more robot controllers can be inserted in a project.

Precondition ■ The catalog **KukaControllers** is available.

- Procedure**
1. Select the **Hardware** tab in the **Project structure** window.
 2. Select the required robot controller in the **KukaControllers** catalog.
 3. Drag the robot controller to **Cell: Hardware view** on the **Hardware** tab.

6.13 Setting the robot controller to active/inactive

Description Most settings, actions and configurations performed in the **Programming and configuration** workspace are only possible if a robot controller is active. Furthermore, they apply to the currently active robot controller (e.g. settings in the safety configuration and I/O mappings).

 If a project contains more than one robot controller, ensure that the correct robot controller is active.

Precondition ■ A robot controller has been added.

- Procedure** **Setting the robot controller as the active controller:**
1. Double-click on the inactive robot controller on the **Hardware** tab in the **Project structure** window.
 2. Only if the robot controller is set to active for the first time: A window opens.
 - **Firmware version** box: Enter the version of the KUKA/VW System Software that is installed on the real robot controller: e.g. "8.2.15".
 - **Number of I/Os** box: Select the maximum number of inputs/outputs used on the robot controller.

The values can be changed subsequently. The correct values are necessary for code generation and project deployment.

(>>> 6.14 "Changing the values "Firmware version" and/or "Number of I/Os"" Page 28)

3. Click on **OK** to save.

Instead of double-clicking, it is also possible to right-click on the robot controller. A context menu is opened. Select the option **Set as active controller**.

Setting the robot controller to inactive:

For a small number of actions in WorkVisual, it is necessary to set the robot controller to inactive. If these actions are started, a message is displayed to inform the user that the robot controller must first be set to inactive.

1. Save the project.
2. Double-click on the active robot controller on the **Hardware** tab in the **Project structure** window.

Instead of double-clicking, it is also possible to right-click on the robot controller. A context menu is opened. Select the option **Set as inactive controller**.

6.14 Changing the values “Firmware version” and/or “Number of I/Os”

Description

When the robot controller is set to active for the first time, the values **Firmware version** and **Number of I/Os** must be adapted or confirmed.

(>>> 6.13 "Setting the robot controller to active/inactive" Page 27)

The values can be changed subsequently. The correct values are necessary for code generation and project deployment.

Procedure

1. Save the project.
2. Right-click on the robot controller on the **Hardware** tab in the **Project structure** window.
3. Select **Controller options** from the context menu. The **Controller options** window is opened.
4. Enter the new value in the **Firmware version** box: e.g. “8.2.16”.
And/or: Select a different number in the **Number of I/Os** box.
5. Click on **OK** to save.

6.15 Removing a robot controller from a project

Procedure

1. Select the **Hardware** tab in the **Project structure** window.
2. Right-click on the robot controller in the **Hardware** tab. Select **Delete** from the context menu.

Alternatively:

Select the robot controller on the **Hardware** tab. Select the menu sequence **Edit > Delete**.

Alternatively:

Select the robot controller on the **Hardware** tab and click on the Delete button in the toolbar or press the Delete key on the keyboard.

The robot controller is removed from the tab.

6.16 Assigning a robot to the robot controller

Description

In the following cases, it is necessary to assign a robot to the robot controller:

- If you want to open the local safety configuration of a robot controller which has not yet been assigned a safety configuration.
- If you want to import the robot’s machine data to the local safety configuration.

- Precondition**
- The catalog containing the required robot has been inserted in the **Catalogs** window.
 - The robot controller has been set as the active controller.
- Procedure**
1. Select the **Hardware** tab in the **Project structure** window.
 2. Select the required robot in the **KukaRobots** catalog in the **Catalogs** window.
 3. Drag the robot onto the robot controller in the **Hardware** tab. (Not onto the node **Unassigned active devices**.)
The robot is now displayed underneath the robot controller.
- Alternative procedure**
1. Select the **Hardware** tab in the **Project structure** window.
 2. Right-click on the robot controller and select **Add...**
 3. A window opens. Select the catalog **KukaRobots**.
 4. Select the required robot from the list and click on the **Add** button.
The robot is now displayed underneath the robot controller.

6.17 Adding an external axis



During project planning, please note the following: If a project is transferred from the robot controller to WorkVisual using **Extras > Compare projects**, then external axes which were added or deleted in the project on the robot controller are not transferred to WorkVisual with the rest of the project.
(>>> 13.8 "Comparing projects (and accepting differences)" Page 110)

- Preparation**
- In order for an external axis to be inserted into the project, the file structure of the robot controller must be present on the **Files** tab in the **Project structure** window. This can be achieved as follows:
- Do not create a new project in WorkVisual, but transfer the initial project from the robot controller to WorkVisual.
(Menu sequence: **File > Browse for project**.)
(>>> 13.7 "Transferring a project from the robot controller to WorkVisual" Page 110)
 - Or: Transfer the project to the robot controller and back to WorkVisual again.
(Menu sequence: **Extras > Compare projects**.)
(>>> 13.8 "Comparing projects (and accepting differences)" Page 110)
- Precondition**
- The **KukaExternalAxis** catalog has been inserted in the **Catalogs** window.
 - The robot controller has been set as the active controller.
- Procedure**
1. Select the **Hardware** tab in the **Project structure** window.
 2. Select the required robot in the **KukaExternalAxis** catalog in the **Catalogs** window.
 3. Drag the external axis onto the robot controller in the **Hardware** tab. (Not onto the node **Unassigned active devices**.)
The external axis is now displayed underneath the robot controller.
 4. Select the external axis and select the menu sequence **Editors > Machine data configuration**. The **Machine data configuration** window is opened.
 5. In the **Axis ID:** box in the area **General axis-specific machine data**, specify which drive the external axis is assigned to in the real cell.

6. If required: edit the other parameters.
7. If the external axis needs to be linked geometrically to a kinematic system:
 - a. Select the **Geometry** tab.
 - b. Assign the kinematic systems to each other as required by means of Drag&Drop.

Example 1: If a KUKA linear unit has been added, drag the robot onto the linear unit.

Example 2: If a servo gun (KUKA.ServoGun package) has been added that is to be used on the robot flange, drag the gun onto the **Flange Base** node of the robot.

6.18 Option packages

6.18.1 Installing an option package in WorkVisual

- Description** Option packages, e.g. technology packages, can be installed in WorkVisual. This makes it possible to insert the catalog of the option package in the individual projects, if required. The option package is then available for use in this project.
- Advantage: if a project is transferred to a number of robot controllers, the settings relevant to the package only need to be carried out once in WorkVisual and not on each individual robot controller.
- Precondition**
- The option package is available as a KOP file.
The KOP file is located on the CD of the option package. (Not yet available for all KUKA option and technology packages.)
 - There is no project open.
- Procedure**
1. Select the menu sequence **Extras > Option package management...**. The **Option package management** window is opened.
 2. Click on the **Install...** button. The **Select the package to be installed** window is opened.
 3. Navigate to the path where the option package is located and select it. Click on **Open**.
 4. The package is installed. If the KOP file contains device description files, the **Update catalog** window opens and closes during this operation.
Once the operation has been completed, the package is displayed in the **Installed option packages** area of the **Option package management** window.




Fig. 6-3: Installed option packages

5. Only if the message *The application must be restarted for the changes to take effect* is displayed:
 - Either: click on the **Restart** button. WorkVisual restarts.
 - Or: close the **Option package management** window and restart WorkVisual later.

6. Only if the message stated in the previous step is NOT displayed: Close the **Option package management** window.

The catalog of the option package is now available under **File > Catalog management...**

If the KOP file contains device description files, these are now available in WorkVisual. It is not necessary to perform a catalog scan.

6.18.2 Updating an option package

Description Only option packages which do not contain an expansion for WorkVisual (e.g. an additional editor) can be updated. Other option packages must first be uninstalled before the new version can be installed.

For the user, it is not apparent beforehand whether a package is updatable or not. The update process can be started nonetheless. If the previous version has to be uninstalled first, WorkVisual displays a message to this effect.

Precondition ■ There is no project open.

- Procedure**
1. Select the menu sequence **Extras > Option package management...**
The **Option package management** window is opened.
 2. Click on the **Install...** button. The **Select the package to be installed** window is opened.
 3. Navigate to the path where the option package is located and select it.
Click on **Open**.
 4. One of the following messages is displayed.
 - **Updating option packages with plug-ins is not possible. Please uninstall '{0}' before updating.**
Confirm the message with **OK**. Do not continue with step 5, but uninstall the package. Then install the new version.
 - **The package has already been installed. Update the package to the selected version?**
Confirm the message with **Yes**.
The package is installed. If the KOP file contains new device description files, the **Update catalog** window opens and closes during this operation.
 5. Only if the message *The application must be restarted for the changes to take effect* is displayed:
 - Either: click on the **Restart** button. WorkVisual restarts.
 - Or: close the **Option package management** window and restart WorkVisual later.
 6. Only if the message stated in the previous step is NOT displayed: Close the **Option package management** window.

6.18.3 Uninstalling an option package

Precondition ■ There is no project open.

- Procedure**
1. Select the menu sequence **Extras > Option package management...**
The **Option package management** window is opened.
 2. In the **Installed option packages** area, click on the red "X" to the right of the name of the package.
 3. Only if the option package is now hidden in the **Installed option packages** area: Close the **Option package management** window.
Uninstallation is now complete. No further steps are necessary.

4. Only if the message *The application must be restarted for the changes to take effect* is displayed:
 - Either: click on the **Restart** button. WorkVisual restarts.
 - Or: close the **Option package management** window and restart WorkVisual later.

If an option package that is used in a project is uninstalled and this project is opened again, the user is prompted to open the catalog for the option package.

If the catalog is not opened, WorkVisual displays the following warning in the message window: **The following option packages of the project are not installed in WorkVisual: {Name}**

6.18.4 Inserting the catalog of the option package into the project

Description If an option package is to be used in a project, the catalog of the option package must be added to this project.

Precondition ■ The option package has been installed in WorkVisual.

Procedure (>>> 6.10 "Inserting a catalog in a project" Page 26)

6.18.5 Removing the catalog of the option package from the project



Elements from the catalog that are used in the project are retained even if the catalog is removed from the project.

Procedure (>>> "Procedure" Page 27)

6.18.6 Inserting an option package in a project



This action is not necessary if a device is added to the project from the option package. In this case, the option package is also inserted automatically.

Description In order to be able to use an option package on the real robot controller, it must be inserted into the project in WorkVisual.



If a project containing an option package is transferred to the robot controller, the procedure differs from the normal deployment procedure. Further information can be found in the section on project deployment.

(>>> 13.4 "Transferring the project to the robot controller" Page 104)

Precondition ■ The catalog of the option package has been added to the project.

Procedure

1. Select the **Hardware** tab in the **Project structure** window.
2. Right-click on the **Options** node and select **Add...**
3. A window opens. Select the catalog of option package.
4. The uppermost element in the catalog is always the option package. Select this and click on the **Add** button.
The option package is now displayed in the **Options** node.

6.18.7 Removing an option package from the project

Precondition

- The robot controller has not been assigned any devices from this option package.
Any devices assigned must first be removed.

Procedure

1. Select the **Hardware** tab in the **Project structure** window.
2. Expand the **Options** node. All the option packages contained in the project are displayed.
3. Right-click on the package to be removed and select **Delete**.
The option package is removed from the **Options** node.

6.18.8 Adding a device from an option package to the robot controller

Description

In order to be able to use devices from the option package on the real robot controller, the devices must be inserted into the project in WorkVisual.

A device is a catalog element to which the following configurations can be assigned:

- Configuration of the device
- Bus configuration
- I/O connections
- Long texts

A device is e.g. a weld controller from KUKA.ArcTech.

Precondition

- The catalog of the option package has been added to the project.

Procedure

1. Select the **Hardware** tab in the **Project structure** window.
2. Right-click on the robot controller and select **Add...**
3. A window opens. Select the catalog of option package.
4. Select the required device from the list and click on the **Add** button.
5. If there are already configurations assigned to the device, a message is displayed asking if these configurations are to be transferred to the project. Select **Yes** or **No** as appropriate.
6. If I/O connections were transferred together with the device, the **Adjust signal connections** window is opened. (>>> Fig. 6-4)
If the signals to which the device is to be connected in accordance with its default settings are already mapped in the current project, this is shown in the **Current conflicts** area.
7. If signals are displayed in the **Current conflicts** area:
If desired, change the start addresses for the different I/O types until no further conflicts are displayed.
8. Either: Click on **OK**. Any signals remaining in the **Current conflicts** area are now overwritten with the new connections.
A message is displayed in the message window for each overwritten connection. This makes it easier in the case of later changes.
Or: Click on **Cancel**. The device is inserted in the **Project structure** window, but no signal connections are adopted.

The device is now displayed underneath the robot controller.




Fig. 6-4: Adjust signal connections

6.18.9 Exporting a subproject

Description This procedure enables parts of projects to be exported, e.g. a device and/or I/O connections. Subprojects can be processed further with the KUKA.OptionPackageEditor. The KUKA.OptionPackageEditor is a software product for manufacturers of technology packages and system integrators for the creation of option packages.

Subprojects have the file format WVPS ("WorkVisual Partial Solution").

Precondition

- A project is open.
- The robot controller has not been set as the active controller.

Procedure

1. Select the menu sequence **File > Import / Export**. A window opens.
2. Select the entry **Export subproject**. The window is now called **Export subproject**. Click on **Next**.
3. All the controllers of the project are displayed. Select the controller from which data is to be exported and confirm with **Next**.
4. A tree structure is displayed. In the tree structure, activate the check boxes for the elements that are to be exported. Confirm with **Next**.
5. Select a path for saving the subproject and click on **Finish**. The subproject is exported.
6. If the export was successful, this is indicated by the following message in the **Export subproject** window: **Partial export successful**. Close the window.

6.19 Changing predefined properties of WorkVisual

6.19.1 Overview

The appearance and the predefined properties of WorkVisual can be changed in the **Options** window.

The window contains various folders:

Folder	Description
Text editor	The KRL Editor can be configured here. (>>> 12.4.4 "Configuring the KRL Editor" Page 91)
Environment	Options for booting and saving can be configured here, together with keyboard shortcuts. (>>> 6.19.2 "Configuring booting and saving characteristics" Page 35) (>>> 6.19.3 "Configuring keyboard shortcuts" Page 35)
Localization	The language of the user interface can be changed here. (>>> 6.19.4 "Changing the user interface language" Page 36)




Fig. 6-5: Options window

6.19.2 Configuring booting and saving characteristics

Procedure

1. Select the menu sequence **Extras > Options**. The **Options** window is opened.
2. In the **Environment** folder, select the subitem **ObjectStoreUI**.
3. Make the desired settings.
4. Confirm the changes made with **OK**.

Description

Subitem **ObjectStoreUI**:

Parameter	Description
Solution directory	A directory can be specified here in which the projects are to be saved by default.
Catalog directory	This specifies the directory in which the catalogs are saved. If the catalogs are moved to a different directory, the directory given here must be changed.
Start application	Here it is possible to specify whether a new project, the most recently opened project or no project is offered for opening when WorkVisual is started.

6.19.3 Configuring keyboard shortcuts

Procedure

1. Select the menu sequence **Extras > Options**. The **Options** window is opened.
2. In the **Environment** folder, select the subitem **Keyboard**.

- In the **Commands** box, select the command for which a keyboard shortcut is to be defined or changed.

The contents of the **Command** box can be filtered:

Enter a term in the box **List only commands with the following content**. Only commands whose names contain this term are now displayed in the **Command** box.

- Place the cursor in the **New shortcut** box and confirm the desired key combination (or individual key) on the keyboard. Examples: **F8** or **Ctrl+F**

The keyboard shortcut is displayed in the **New shortcut** box.

- Click on **Assign**.
- Confirm the change with **OK**.

Or: If the keyboard shortcuts are already assigned, a request for confirmation is displayed:

- If the keyboard shortcut is to be assigned to the new command, select **Yes** and confirm the changes with **OK**.
- If the keyboard shortcut is to remain assigned to the old command, select **No**.

Close the window by selecting **Cancel**. Or delete the keyboard shortcut from the **New shortcut** box using the **Esc** key, and enter a different one.

6.19.4 Changing the user interface language

Precondition

To be able to select the language Chinese, Japanese or Korean:

- This language must also be installed as a Windows language.

Procedure

- Select the menu sequence **Extras > Options**. The **Options** window is opened.
- Select the **Localization** folder.
- Select the desired language from the **Language** box. Click **OK** to confirm.
- Close and restart the application.

6.20 Print functions

The procedure described here can be used to print the following:

- I/O connections
- Long texts
- Safety configuration

Procedure

- Select the menu sequence **File > Print**. The **Print** window is opened.
- Select the desired printer in the **Printer** area. If required, change the printer settings.
- In the **Document** area, select the relevant checkboxes to indicate what should be printed.
- If required, first display the print preview: To do this, click on the **Preview** button.
Close the print preview again.
- Click on the **Print** button to start printing.

It is also possible to print directly from the print preview, via the button with the printer symbol. In this case, the standard printer is used. Changes to the printer settings are not possible.

Description

Print window, **Documents** area:

Check box	Description
Global	This function is not yet assigned.
Cell	If this checkbox is activated, all the robot controllers belonging to this cell are automatically activated. Individual controllers can be deactivated again manually.
Controller [...]	If this checkbox is activated, all the documents belonging to this robot controller are automatically selected for printing. Individual documents can be deactivated again manually.
Documents:	
Connection list	Prints the I/O connections defined in the I/O Mappings window.
Long texts	If long texts have been defined in various languages, it is also possible to select which languages should be printed.
Safety configuration	The printout contains a date and signature box and can be used as a sign-off sheet for the safety acceptance procedure.

7 Safety configuration

7.1 Safety configuration in WorkVisual

The safety configuration in WorkVisual comprises the following areas:

Area	Description
Local safety configuration	The local safety configuration comprises the parameters in the Local safety configuration window. The parameters can be edited. (>>> 7.2 "Editing the local safety configuration" Page 39)
Safety-relevant communication parameters	These include the parameters relevant to safe communication within a robot network. The safety-relevant communication parameters cannot be displayed or edited directly. However, various actions in WorkVisual have an effect on the safety-relevant communication parameters, e.g. if a RoboTeam is configured.

When a project is transferred to the real robot controller, the entire safety configuration is always transferred at the same time.

7.2 Editing the local safety configuration

Description

A newly added robot controller is without a local safety configuration in WorkVisual. A robot controller without a local safety configuration can be recognized by the fact that the text of the **Safety controller** node on the **Hardware** tab in the **Project structure** window is in italics: *Safety controller*

The robot controller is automatically assigned a local safety configuration in WorkVisual when the **Local safety configuration** window is opened.

The local safety configuration can be edited in WorkVisual. The changes always apply to the robot controller which is currently set as active.

Precondition

- A robot controller has been added and set as active.
- If the robot controller has not yet been assigned a local safety configuration: A robot has been assigned to the robot controller.
(>>> 6.16 "Assigning a robot to the robot controller" Page 28)

Procedure

1. Select the menu sequence **Editors > Safety configuration (local)**. The **Local safety configuration** window is opened.
2. If this has not already been done:
In the **Overview** area of the **General** tab, select the safety option used: SafeOperation, SafeRangeMonitoring, or none.
3. If SafeOperation or SafeRangeMonitoring is used: Activate the **Safe monitoring** checkbox in the **Global parameters** area of the **Common** tab.
(Only then are the monitoring functions displayed and can be edited.)
4. Modify the parameters as required.
5. Close the **Local safety configuration** window.



Some parameters of the local safety configuration are always displayed.

Parameters referring to SafeOperation or SafeRangeMonitoring are only displayed if one of these options is selected on the **General** tab. Information on these parameters can be found in the documentation for **KUKA.SafeOperation** and **KUKA.SafeRangeMonitoring**.

7.3 “General” tab

Hardware options

Parameter	Description
Customer interface	Select here which interface is used: <ul style="list-style-type: none"> ■ ProfiSafe ■ SIB ■ SIB, Extended SIB ■ SIB with operating mode output ■ SIB with operating mode output, Extended SIB This option is available with System Software version 8.2.4 or higher.
Input signal for peripheral contactor (US2)	Main contactor 2 can be used as a peripheral contactor, i.e. as a switching element for the power supply to peripheral devices. <p>Deactivated: Peripheral contactor is not used (default).</p> <p>By external PLC: The peripheral contactor is switched by an external PLC via input US2.</p> <p>By KRC: The peripheral contactor is switched in accordance with the motion enable. If motion enable is present, the contactor is energized.</p>
Operator safety acknowledgement	If the Operator Safety signal is lost and reset in Automatic mode, it must be acknowledged before operation can be continued. <p>By acknowledgement button: Acknowledgement is given e.g. by an acknowledgement button (situated outside the cell). Acknowledgement is communicated to the safety controller. The safety controller re-enables automatic operation only after acknowledgement.</p> <p>External unit: Acknowledgement is given by the system PLC.</p>

Change log

Every modification to the local safety configuration and every saving operation are automatically logged. The log is displayed here.

Machine data

The machine data of the safety controller are displayed here.

(>>> 7.4 "Importing machine data into the local safety configuration" Page 40)

7.4 Importing machine data into the local safety configuration

Description

In the following cases it is possible to import machine data into the local safety configuration:

- If a robot controller has been assigned a kinematic system.

- Or if machine data files exist in the project (e.g. if the project has been transferred from a real robot controller to WorkVisual).

This import is necessary, e.g. if an external axis has been added to the project and settings are to be made for it in the safety configuration. The corresponding parameters are only displayed in the safety configuration after the import.

⚠ WARNING If the machine data are imported into the local safety configuration in WorkVisual, it is still imperative to check the local safety configuration again on the real robot controller after the project has been transferred.
(>>> 13.6 "Checking the safety configuration of the robot controller" Page 110)

- Precondition**
- The robot controller has been set as the active controller.
 - A robot has been assigned to the robot controller.

- Procedure**
1. Select the menu sequence **Editors > Safety configuration (local)**. The **Local safety configuration** window is opened.
 2. Select the **General** tab and then the **Machine data** option.
 3. Click on the **Import machine data** button.
 4. If the machine data were imported successfully, this is indicated by a message in the message window.
 5. Close the **Local safety configuration** window.

7.5 Importing a local safety configuration

⚠ WARNING After importing a safety configuration or parts thereof, the safety configuration must be checked! If this is not done, this can lead to the possibility of the robot being operated with incorrect data when the project is transferred to the real robot controller. Death to persons, severe physical injuries or considerable damage to property may result.

- Precondition**
- The robot controller has been set as the active controller.

- Procedure**
1. Select the menu sequence **File > Import / Export**. The **Import/Export Wizard** window is opened.
 2. Select **Import local safety configuration** and click on **Next**.
 3. Navigate to the path where the SCG file is located and select it. Click on **Open**.
 4. Click on **Finish**.
 5. If the configuration was imported successfully, this is indicated by a message. Close the **Import/Export Wizard** window.

7.6 Exporting a local safety configuration

Description The local safety configuration is exported as an SCG file.

- Precondition**
- The robot controller has been set as the active controller.

- Procedure**
1. Select the menu sequence **File > Import / Export**. The **Import/Export Wizard** window is opened.
 2. Select **Export local safety configuration** and click on **Next**.
 3. Specify a directory and a file name. Click on **Finish**.
 4. If the configuration was exported successfully, this is indicated by a message. Close the **Import/Export Wizard** window.

7.7 Importing safety zones



WARNING After importing a safety configuration or parts thereof, the safety configuration must be checked! If this is not done, this can lead to the possibility of the robot being operated with incorrect data when the project is transferred to the real robot controller. Death to persons, severe physical injuries or considerable damage to property may result.

Description

Certain parts of the local safety configuration can be imported as an XML file. These parts are referred to here as “Safety zones” and comprise:

- Cell configuration
- Monitoring spaces (Cartesian spaces and/or axis spaces)
- Properties of the tools

The XML file can be created by the user on the basis of data from CAD systems, etc. The required structure of the XML file is described in the schema **SafetyConfigImport.xsd**. This is located in the following directory:

C:\Program Files\KUKA\WorkVisual [*version number*]\Schemes

Precondition

- The robot controller has been set as the active controller.
- In the safety configuration, one of the following options is selected in the **Overview** area of the **General** tab: **SafeOperation** or **SafeRangeMonitoring**

Procedure

1. Save the project. (Do not close.)
2. Select the menu sequence **File > Import / Export**. A window opens.
3. Select the entry **Import local safety configuration**. The window is now called **SafetyConfigImport**.
Click on **Next**.
4. Click on **Search...**. Navigate to the path where the XML file is located and select it. Click on **Open**.
If the XML file contains schema errors, this is indicated by a message in the **SafetyConfigImport** window. (The data can still be imported.)
5. If required: Activate the check box *Show differences*.
If this option is activated, the differences between the existing values and those to be imported are displayed before the import is carried out.
6. Click on **Finish**. In the background, the window **Local safety configuration** is opened, if not already open.
If *Show differences* is not activated: the data are now imported.
7. If *Show differences* is activated: the overview is displayed. (>>> Fig. 7-1)
Click on **Import**. The data are now imported.
8. When the import is finished, this is indicated by the following message: **The local safety configuration was imported successfully**. This message is also displayed if errors were imported.
Close the **SafetyConfigImport** window.



If errors were imported, this is indicated by messages in the message window.

9. Check the safety configuration. The data are displayed in the **Local safety configuration** window in the following colors:
 - **Red**: This value was changed by the import. The value is invalid.
 - **Blue**: This value was changed by the import. The value is valid.

i Blue does not automatically mean that this is the value from the XML file! It is possible, for example, that the XML file contained a value which cannot be interpreted by WorkVisual, e.g. "2" where only "0" or "1" is possible. In this case, WorkVisual sets the default value and displays this in blue.

10. Correct the invalid values. (If invalid values are present, the project cannot be saved.)

11. Save the project to accept the imported data.

i The imported data are only accepted when the project is saved. This also means that imported data can be discarded by closing the project without saving.

Show differences

Parameter name	Current value	Import value
Cell configuration		
Z min	234	234
Z max	1200	1200
Corner 1		
X	-800	-1000
Y	800	1000
enabled	enabled	enabled
+ Corner 2		
+ Corner 3		
+ Corner 4		
Tools		
+ Tool 1		
Monitoring spaces		
+ Space 1		
+ Space 2		
GlobalParameters		
Mastering test input	by Profisafe	by Profisafe
Cartesian maximum velocity	3000	3000
Reduced cartesian velocity	3000	3000
Reduced cartesian velocity T1	200	200
Maximum velocity rotational axis	120	120
Maximum velocity translational axis	3000	3000

Fig. 7-1: Example: Displaying the differences

Color	Meaning
Red	With this element (or its child elements), the existing value differs from the value to be imported.
Black	With this element (including all its child elements), the existing value is identical to the value to be imported.

8 Bus configuration

8.1 Configuring the bus

8.1.1 Overview: Bus configuration

Step	Description
1	Install the device description files on the PC. (>>> 6.8 "Importing device description files" Page 25)
2	Insert the DTM Catalog in the Catalogs window. (>>> 6.10 "Inserting a catalog in a project" Page 26)
3	Insert the field bus master in the project. (>>> 8.1.2 "Inserting a field bus master in a project" Page 45)
4	Configure the field bus master. (>>> 8.1.3 "Configuring the field bus master" Page 46)
5	Add the devices to the bus, i.e. insert them under the field bus master. (>>> 8.1.4 "Inserting devices manually into the bus" Page 46) Or: (>>> 8.1.7 "Automatically inserting devices into the bus (Bus Scan)" Page 49)
6	Configure the devices. (>>> 8.1.5 "Configuring devices" Page 46) Or (only possible for PROFINET): (>>> 8.1.6 "Importing a PROFINET configuration" Page 47)
7	Edit the field bus signals (>>> 8.2 "Editing field bus signals" Page 50)
8	The bus I/Os can now be mapped. (>>> 8.3 "Mapping the bus I/Os" Page 55)

8.1.2 Inserting a field bus master in a project

- Precondition**
- The device description files are inserted in the DTM Catalog (Catalog Scan).
 - The robot controller has been added and set as active.

- Procedure**
1. Expand the tree structure on the **Hardware** tab in the **Project structure** window until the **Bus structure** node is visible.
 2. Right-click on **Bus structure** and select **Add** from the context menu. The **DTM selection** window is opened.
 3. Select the required field bus master and confirm with **OK**. It is inserted in the tree structure.

- Alternative procedure**
1. Expand the tree structure on the **Hardware** tab in the **Project structure** window until the **Bus structure** node is visible.
 2. Select the required field bus master in the **DTM Catalog** window and drag it onto the **Bus structure** node.

8.1.3 Configuring the field bus master

- Precondition**
- The field bus master is inserted in the project.
 - The robot controller has been set as the active controller.
- Procedure**
1. Right-click on the field bus master on the **Hardware** tab in the **Project structure** window.
 2. Select **Settings...** from the context menu. A window opens with device data.
 3. Set the data as required and save with **OK**.

NOTICE	The following address ranges are used by default by the robot controller for internal purposes. IP addresses from this range must not therefore be assigned by the user.
■	192.168.0.0 ... 192.168.0.255
■	172.16.0.0 ... 172.16.255.255
■	172.17.0.0 ... 172.17.255.255

	Information about settings for particular bus systems can be found in the documentation for these bus systems.
---	--

8.1.4 Inserting devices manually into the bus

NOTICE	The inserted device must correspond to the actual device used in reality. Substantial damage to property may otherwise result.
---------------	--

- Precondition**
- The devices are inserted in the DTM Catalog.
 - The field bus master is inserted in the bus structure.
 - The robot controller has been set as the active controller.
- Procedure**
1. Expand the tree structure on the **Hardware** tab in the **Project structure** window until the field bus master is visible.
 2. Right-click on the field bus master and select **Add...** from the context menu. The **DTM selection** window is opened.
 3. Select the desired device and confirm with **OK**. The device is inserted in the tree structure.
 4. If necessary, repeat steps 2 and 3 for further devices.
- Alternative procedure**
1. Expand the tree structure on the **Hardware** tab in the **Project structure** window until the field bus master is visible.
 2. Select the required device in the DTM Catalog and drag it onto the field bus master.
 3. If necessary, repeat step 2 for further devices.

8.1.5 Configuring devices

- Precondition**
- The device has been added to the bus.
 - The robot controller has been set as the active controller.
- Procedure**
1. Right-click on the device on the **Hardware** tab in the **Project structure** window.
 2. Select **Settings...** from the context menu. A window with the device data is opened.

3. Set the data as required and save with **OK**.

NOTICE The following address ranges are used by default by the robot controller for internal purposes. IP addresses from this range must not therefore be assigned by the user.

- 192.168.0.0 ... 192.168.0.255
- 172.16.0.0 ... 172.16.255.255
- 172.17.0.0 ... 172.17.255.255

 Information about settings for particular bus systems can be found in the documentation for these bus systems.

8.1.6 Importing a PROFINET configuration

Description A PROFINET bus can also be configured with Step 7 or PC WORX instead of with WorkVisual. This configuration must then be imported into WorkVisual.

Preparation WorkVisual requires the GSDML files of the PROFINET devices used. (The device description files for PROFINET are called GSDML files.)

- Import the files.
(>>> 6.8 "Importing device description files" Page 25)

Precondition

- The robot controller has been set as the active controller.
- The PROFINET configuration has been exported out of Step 7 or PC WORX and is available as an XML or CFG file.

 Information about configuring PROFINET with Step 7 or PC WORX can be found in the documentation **KR C4 PROFINET**. Information about procedures in Step 7 or PC WORX can be found in the documentation for this software.

Procedure

1. Select the menu sequence **File > Import / Export**. The **Import/Export Wizard** window is opened.
2. Select **Import Profinet configuration** and click on **Next**.
3. Click on the **Browse...** button and navigate to the path where the XML or CFG file is located and select it. Click on **Open**.
4. Click on **Next**.
5. A tree structure is displayed. This shows whether the PROFINET configuration corresponds to the devices in the project. If not, the difference is displayed. If necessary, the import can be canceled at this point with **Cancel**.
(>>> 8.1.6.1 "Differences between the PROFINET configuration and the project" Page 47)
Otherwise, click on **Finish**. This is also possible if the configuration differs from the devices in the project. If there is a difference:
 - The PROFINET configuration overwrites the state in the project.
 - The nature of the difference determines whether the I/O mappings in the project are retained or not.
6. If the configuration was imported successfully, this is indicated by a message. Close the **Import/Export Wizard** window.

8.1.6.1 Differences between the PROFINET configuration and the project

If the device is marked with a green check mark, this means that there is no difference. The device is identical in the PROFINET configuration and in the project.

If there are differences, these are displayed during import of the PROFINET configuration as follows:

Device missing

Difference	The device is contained in the PROFINET configuration but not in the project.
Icon	Green cross
Effect on import	The device is inserted into the bus in the project.




Fig. 8-1: Device not in project

Device too many

Difference	The device is contained in the project but not in the PROFINET configuration.
Icon	Red X
Effect on import	The device is deleted from the bus in the project. I/O mappings to this device are also deleted!




Fig. 8-2: Device not in import

IP settings

Difference	The IP settings of this device in the project are different from those in the PROFINET configuration. (boxes IP address , subnet mask or standard gateway)
Icon	Pen
Effect on import	The IP settings of the PROFINET configuration are applied to the project. The I/O mappings of this device are retained.




Fig. 8-3: IP settings changed in WorkVisual

Module assignment

Difference	The module assignment of this device in the project is different from that in the PROFINET configuration.
------------	---

Icon	Double arrow
Effect on import	The module assignment of the PROFINET configuration is applied to the project. I/O mappings to this device are deleted!




Fig. 8-4: Different module assignment

PROFINET name

Difference	The PROFINET name of this device in the project is different from that in the PROFINET configuration. WorkVisual regards the device as 2 different devices.
Icon	Red X and green cross
Effect on import	The device is added to the project from the configuration. The device that was previously in the project is deleted. The I/O mappings to this device are also deleted!




Fig. 8-5: Different PROFINET name

i In the tree structure, the product name is displayed, not the PROFINET name of the device. That is why the names are the same here.

Text color

The text color is normally black.

Text color	Meaning
Orange	No GSDML file can be clearly assigned to this device. The relevant possible files are listed in the selection box. The user must choose a file.
Red	No GSDML file is available in WorkVisual for this device. The user must make the file available. (>>> "Preparation" Page 47)

8.1.7 Automatically inserting devices into the bus (Bus Scan)**Description**

The bus scan is available for Interbus and EtherCAT.

The bus devices can be inserted automatically. For this, the user can start a scan in WorkVisual to determine which devices are connected to the real bus. The corresponding devices are then inserted automatically into the bus structure in WorkVisual.

In contrast to manual insertion, this procedure is faster and less susceptible to error.

Precondition

- The devices are inserted in the DTM Catalog.
- The field bus master is inserted in the bus structure.
- The robot controller has been set as the active controller.
- Network connection to the real robot controller
- The devices are connected to the real robot controller.



There are further preconditions depending on the bus system used. Information about this is contained in the documentation for the different bus systems.

Procedure

1. Expand the tree structure of the robot controller on the **Hardware** tab in the **Project structure** window.
2. Right-click on the field bus master. Select the option **Scan Topology...** and then select a channel. The **Topology Scan Wizard** window is opened.
3. Click on **Continue** to start the scan. When the scan is completed, WorkVisual displays all the devices found in the window on the left. Each device is represented by a number (= product code).
4. Select a device. In the window on the right, WorkVisual displays a list of the device description files which have the same product code.
5. If the list contains a number of device description files, scroll down the list and check if the file of the device that is actually used is selected. If a different file is marked, select the option **Manual selection** and select the correct file.
6. Repeat steps 4 and 5 for all devices shown.
7. Click on **Continue** to confirm the assignment.
8. Click on **Finish** to assign the devices to the field bus master.

8.2 Editing field bus signals

Description

Field bus signals can be edited in WorkVisual. For example, the signal width can be changed or the byte order can be swapped.

Precondition

- The field bus devices are configured.

Procedure

1. Select the device on the **Field buses** tab in the **I/O Mapping** window.
2. In the **I/O Mapping** window, click on the **Edit signals at the provider** button. The **Signal Editor** window is opened. All inputs and outputs of the device are displayed.
(>>> 8.2.1 "Signal Editor" Page 50)
3. Edit the signals as required.
4. Click on **OK** to save the changes and close the **Signal Editor** window.

8.2.1 Signal Editor

In the Signal Editor, the inputs of the selected device are displayed on the left and the outputs on the right.




Fig. 8-6: Signal Editor

Item	Description
1	The left-hand column displays the original configuration of the inputs or outputs. Each box represents 1 bit.
2	The right-hand column can be edited and always displays the current configuration of the inputs or outputs. Each box represents 1 bit.
3	Signal name (>>> 8.2.5 "Changing signal names" Page 54)
4	Start mark for swapping (>>> 8.2.3 "Swapping signals (reversing the byte order)" Page 52)
5	Address at which this signal starts
6	Signal width (>>> 8.2.2 "Changing the bit width of signals" Page 52)
7	Address to which this bit belongs, and number of the bit
8	The bar indicates that the byte order has been swapped.
9	Boundary between memory segments
10	Data type of this signal (>>> 8.2.4 "Changing the data type" Page 54)

8.2.2 Changing the bit width of signals

Description

This procedure can be used to change the width of signals. Signals can be split or grouped. It is also possible to split signals more than once.

The signal boundaries can be moved only as far as the boundaries of the memory segments. Signal boundaries cannot be moved beyond the boundaries of swapped ranges.

Bits that are being edited are indicated in red.

Precondition

- The Signal Editor is open.
- The signals that are to be edited are not mapped.

Procedure

Moving a signal boundary:

1. In the right-hand column, position the mouse pointer over the boundary line between 2 signals. The mouse pointer changes into a vertical double arrow.
2. Click and hold down the mouse button and move the mouse pointer up or down. The boundary line is moved.
3. Drag the boundary line to the desired position and let go.

This procedure can be used to reduce a signal down to the size of 1 bit.

Splitting a signal:

1. In the right-hand column, position the mouse pointer over a bit.
2. Click and hold down the mouse button and move the mouse pointer up or down. A line is displayed over the output bit.
3. Drag the mouse pointer to another bit and let go. A line is also displayed over this bit. The two lines are the boundaries of the new signal.

Grouping signals:

1. In the right-hand column, position the mouse pointer over the first (or last) bit of a signal.
2. Click and hold down the mouse button and move the mouse pointer down (or up).
3. Drag the mouse pointer across a signal boundary to another signal boundary and let go. The intervening signal boundary disappears. The signals have been grouped.

8.2.3 Swapping signals (reversing the byte order)

Description

The byte order of signals can be swapped. It is possible to swap 2, 4 or 8 bytes at once. Sub-ranges of signals cannot be swapped. Furthermore, it is not possible to swap across the boundaries of memory segments.

The bits within a byte always remain unchanged.

 The (V)KR C4 robot controller uses the Intel data format. Field bus signals in Motorola format must be converted to Intel. This is done by means of swapping.

i It is not always clear from the manufacturer's data sheets whether a signal needs to be swapped or not. The signals of Siemens devices generally need to be swapped. The following procedure can provide information about whether it is necessary to swap an input:

1. Change the voltage on the input slowly and evenly.
2. Observe the values for this signal in the **Analog I/O** window on the KUKA.smartHMI.

If the values change abruptly and unevenly or in different directions, this is an indication that swapping is necessary.

It makes a difference whether a range is swapped as a whole or in parts:




Fig. 8-7: Example 1: Swapping the byte order

Item	Description
1	Original order
2	Result of swapping the bytes in two groups (i.e. the first two bytes are swapped and the second two bytes are swapped separately.)




Fig. 8-8: Example 2: Swapping the byte order

Item	Description
1	Original order
2	Result of swapping all the bytes at once

Precondition

- The Signal Editor is open.

Procedure

1. Position the mouse pointer over a start mark for swapping. The mouse pointer changes into a vertical double arrow.
2. Click and hold down the mouse button. Move the mouse pointer downwards to the signal boundary.
3. A bar is displayed.
 - Either: Release the mouse button. The byte order has now been swapped.
 - Or: If a larger range is to be swapped, keep moving the mouse pointer without letting go. A longer bar is displayed. Release the mouse button. The byte order has now been swapped.

An end mark for swapping is displayed.

To undo the swapping:

1. Position the mouse pointer over an end mark for swapping. The mouse pointer changes into a vertical double arrow.
2. Click and hold down the mouse button. Move the mouse pointer up towards the start mark.
3. The bar disappears. The swapping has been undone.

8.2.4 Changing the data type

Description In the Signal Editor, the data type is displayed by an icon.

Icon	Description
	Integer data type with sign (depending on the length: SINT, INT, LINT or DINT)
	Integer data type without sign (depending on the length: USINT, UINT, ULINT or UDINT)
	Digital data type (depending on the length: BYTE, WORD, DWORD or LWORD)

(The exact data type of a signal is displayed in the **I/O Mapping** window.)

The data type must be changed e.g. if a signal needs to be used as an analog output or input but is only designated as a digital data type in the device description file.

Precondition ■ The Signal Editor is open.

Procedure

1. Click on the icon for the sign on the right-hand side of the input or output column. The icon changes.
2. Click until the desired symbol is displayed.

8.2.5 Changing signal names

Precondition ■ The Signal Editor is open.

Procedure

1. Click on the name of the input or output in the right-hand column. The name can now be edited.
2. Enter the desired name and confirm with the Enter key.
The name must be unambiguous within the current view of the Signal Editor.

The changed name is displayed in the **I/O Mapping** window.

8.3 Mapping the bus I/Os

8.3.1 I/O Mapping window

Overview




Fig. 8-9: I/O Mapping window

Item	Description
1	Display of the input/output types and field bus devices. The two areas to be connected are selected on the left and right via tabs. The signals in the areas selected here are displayed in the windows lower down.
2	Display of the mapped signals
3	Display of all signals. The inputs/outputs can be mapped here. (>>> 8.3.3 "Mapping input to output" Page 57)
4	This allows the two signal displays to be collapsed and expanded independently of one another.
5	Displays how many bits the selected signals contain

Mapped signals are indicated by green symbols.

Multiply mapped signals are indicated by double arrows: 

(>>> 8.3.2 "Buttons in the I/O Mapping window" Page 56)

Tabs:

Name	Description
KR C I/Os	Here the analog and digital inputs/outputs of the robot controller are displayed. There is a KR C I/Os tab on the left and on the right. This makes it possible to map inputs and outputs of the robot controller with each other.
PLC	These tabs are only relevant if Multiprog is used.
KR C signals	Here the other signals of the robot controller are displayed.
Field buses	Here the inputs/outputs of the field bus devices are displayed.

8.3.2 Buttons in the I/O Mapping window

Filter/ Search

Some of these buttons are displayed in several places. In such cases, they refer to the side of the **I/O Mapping** window on which they are located.

With some buttons, the tool tip changes depending on whether the signals they refer to are shown or hidden.

Button	Name / description
	Filter inputs/Display all inputs: Shows and hides the inputs.
	Filter outputs/Display all outputs: Shows and hides the outputs.
	<p>Filter dialog: The Filter signals window is opened. Enter filter criteria (name, data type and/or signal range) and click on the Filter button. Signals that conform to these criteria are displayed.</p> <p>When a filter is set, the button displays a green check mark at bottom right. To remove a filter that has been set, click on the button and, in the Signals window, click on the Reset button and then on Filter.</p>
	<p>Buttons above the “connected signals” window:</p> <p>Search for the connected signal: Only available if a mapped signal is selected.</p> <p>(>>> 8.3.6 "Searching for assigned signals" Page 59)</p> <p>Button below the “all signals” window:</p> <p>Search text: Displays a search box. Here it is possible to search the signal displays for signal names (or parts of names), either upwards or downwards.</p> <p>When the search box is displayed, the button displays a cross at bottom right. To hide the search box again, click on the button.</p>
	Filter connected signals/Display all connected signals Shows and hides the connected signals.
	Filter disconnected signals/Display all unconnected signals Shows and hides the unconnected signals.

Mapping

Button	Name / description
	Disconnect: Disconnects the selected mapped signals. It is possible to select and disconnect a number of connections simultaneously.
	Connect: Connects signals which are selected in the "all signals" display. It is possible to select a number of signals on both sides and connect them at one go. (Only possible if the same number of signals is selected on both sides.)

Edit

Button	Name / description
	Creates signals at the provider Only relevant if Multiprog is used.
	Edit signals at the provider For field bus signals: opens an editor in which the bit assignment of the signals can be edited. (>>> 8.2 "Editing field bus signals" Page 50) Editing options are also available here for the analog inputs/ outputs of the KRC and for Multiprog signals. (>>> 8.3.8 "Editing analog KRC signals" Page 60)
	Deletes signals at the provider Only relevant if Multiprog is used.



Information about Multiprog is contained in the **KUKA.PLC Multiprog** documentation.

8.3.3 Mapping input to output

Description

This procedure is used to assign the inputs and outputs of the devices to the inputs and outputs of the robot controller.

By the same principle, it is also possible to map inputs and outputs of the robot controller to each other. (In this case, the **KR C I/Os** tab must be used in both halves of the window.)

Precondition

- The robot controller has been set as the active controller.
- The bus configuration in WorkVisual corresponds to the real bus configuration.
- The field bus devices are configured.

Procedure

1. Click on the **Opens the I/O Mapping Editor** button. The **I/O Mapping** window is opened.
2. On the **KR C I/Os** tab in the left-hand half of the window, select the area of the robot controller that is to be mapped, e.g. **Digital inputs**.
The signals are displayed in the bottom area of the **I/O Mapping** window.
3. Select the device on the **Field buses** tab in the right-hand half of the window.
The signals of the device are displayed in the bottom area of the **I/O Mapping** window.
4. Drag the signal of the robot controller onto the input or output of the device. (Or alternatively, drag the input or output of the device onto the signal of the robot controller.)
The signals are now mapped.

Alternative procedure for mapping:

- Select the signals to be mapped and click on the **Connect** button.
- Or: Select the signals to be mapped and select the **Connect** option from the context menu.

Multiple mapping:

It is possible to select a number of signals simultaneously (on both sides) and connect them at one go. A further possibility is as follows:

1. Select a number of signals on one side and one signal on the other side.
2. Select the option **Connect continuously** from the context menu. The signals are connected (counting upwards), starting from the one selected signal.

8.3.4 Mapping bus input to bus output

Description A bus input can be mapped to a bus output (in the same or a different bus). This is done indirectly. A total of 3 mappings are required for this.

Procedure

1. Map the bus input to an input of the robot controller.
2. Map the robot controller input to a robot controller output.
3. Map the robot controller output to a bus output.

The input and output of the robot controller are thus multiply mapped in this case.


Schematic

Fig. 8-10: Schematic: Mapping bus input to bus output

8.3.5 Multiple mapping or reverse mapping of signals

Possible Signals can be multiply mapped. Multiply mapped signals are indicated in the **I/O Mapping** window by a double arrow: 

The following multiple mapping is possible:

- Map an input (robot controller) to an input (bus).
- Map the same input (robot controller) to one or more outputs (robot controller).




Fig. 8-11: Multiple mapping possible

The following reverse mapping is possible:

- Map an output (bus) to an input (robot controller).



Fig. 8-12: Reverse mapping possible

Not possible

The following multiple mappings are not possible:

- Map an input (robot controller) to several inputs (bus).
- Map an output (robot controller) to several outputs (bus).




Fig. 8-13: Multiple mapping not possible

8.3.6 Searching for assigned signals

Procedure

1. Select a mapped signal.
2. In the part of the window in which the signal was selected (left-hand or right-hand half), click on the button **Searches for the connected signal**.
 - If a signal is mapped once: the assigned signal is now highlighted in the other half of the “all signals” window.
 - If a signal is multiply mapped: the **Search for signal** window opens. All signals connected with the selected signal are shown. Select a signal and confirm with **OK**.




Fig. 8-14: Example: Multiply mapped signal

8.3.7 Grouping signals

Description

8 digital inputs or outputs of the robot controller can be grouped together to a signal of the data type BYTE. Grouped signals can be recognized by the name extension **#G**.

Precondition

- The signals that are to be grouped are not mapped.

Procedure

1. Below the **KR C I/Os** tab, select 8 consecutive signals and right-click on them.
2. Select **Group**.
The signals are grouped to a signal of type BYTE. The name with the lowest index number is taken for the new signal.

To undo the grouping:

1. Right-click on a signal with the name extension **#G**.
2. Select **Ungroup**.

Example




Fig. 8-15: Group signals



Fig. 8-16: A grouped signal

8.3.8 Editing analog KRC signals

Procedure

1. Select the analog signal on the left-hand **KR C I/Os** tab in the **I/O Mapping** window.

It is also possible to select and edit several signals at once: Consecutive signals can be selected using SHIFT + click. A number of individual signals can be selected using CTRL + click.

2. At the bottom left of the **I/O Mapping** window, click on the button **Edit signals at the provider**. A window opens.
3. Enter the required calibration factor and change the data type if necessary.
4. Click on **OK** to save the data and close the window.

Box	Description
Calibration factor	The required calibration factor can be entered here.
Type	Only signals of the same type can be connected. The data type can be changed here.

8.4 Exporting the bus configuration

Description The bus-specific configuration can be exported in the form of XML files. This export makes it possible to check the configuration files if required.

If desired, the files can be copied onto the real robot controller. This is not necessary, however, if the project is transferred to the robot controller online.

(>>> 13.4 "Transferring the project to the robot controller" Page 104)

Precondition ■ The robot controller has been set as the active controller.

Procedure

1. Select the menu sequence **File > Import / Export**. The **Import/Export Wizard** window is opened.
2. Select **Export I/O configuration to .XML files** and click on **Next**.
3. Specify a directory. Click on **Next**.
4. Click on **Finish**.
5. The configuration is exported to the specified directory. If the configuration was successfully completed, this is indicated by a message.
Close the **Import/Export Wizard** window.

9 Long texts

9.1 Displaying / editing long texts

Precondition ■ A robot controller has been added and set as active.

- Procedure**
1. Select the menu sequence **Editors > Symbol Table Editor**.
 2. The long texts are sorted thematically. In the left-hand column, select which long texts are to be displayed, e.g. **Digital inputs**.
 3. In the other columns, select the language or languages that are to be displayed.
 4. Edit the long texts, if necessary.

Description




Fig. 9-1: Symbol Table Editor

 The long texts of the digital inputs/outputs can also be edited in the **I/O Mapping** window via the **Edit signals at the provider** button. ([>>> 8.3.1 "I/O Mapping window" Page 55](#))

9.2 Importing long texts

Description The following file formats can be imported:

- .TXT
- .CSV

 Imported long texts overwrite existing long texts.

Precondition ■ A robot controller has been added and set as active.

- Procedure**
1. Select the menu sequence **File > Import / Export**. The **Import/Export Wizard** window is opened.
 2. Select **Import Symbol Table** and click on **Next**.
 3. Select the file to be imported and the language of the contained long texts.
 4. If a signal already has a name and the file to be imported does not contain a name for this signal, the check box **Delete existing entries** determines what happens to the existing name.
 - **Activated:** The name is deleted.
 - **Not activated** The name is retained.



Fig. 9-2: Importing long texts

5. Click on **Finish**.
6. If the import was successful, this is indicated by a message in the **Import/Export Wizard** window. Click on **Close** to close the window.

9.3 Exporting long texts

Description

Long texts can be exported in the following file formats:

- .TXT
- .CSV

Precondition

- A robot controller has been added and set as active.

Procedure

1. Select the menu sequence **File > Import / Export**. The **Import/Export Wizard** window is opened.
2. Select **Export SymbolTable** and click on **Next**.
3. Specify the path name and format of the file which is to be generated. Also select the language. Click on **Finish**.



Fig. 9-3: Exporting long texts

4. If the export was successful, this is indicated by a message in the **Import/Export Wizard** window. Click on **Close** to close the window.

10 Configuring the controller bus, extension bus, system bus

10.1 Overview

Description

The system configuration of the industrial robot must be configured using WorkVisual in the following cases:

- Installation of KSS/VSS 8.2
This is the case if a KSS/VSS 8.2 package is installed without KSS/VSS 8.2 already being present (because it has been uninstalled or deleted or has never been installed).
- The hard drive has been exchanged.
- A device has been replaced by a device of a different type.
- More than one device has been replaced by a device of a different type.
- One or more devices have been removed.
- One or more devices have been added.

 Once the hard drive has been exchanged, the archive of the previous installation can be loaded (as an alternative to configuration using WorkVisual).

 Information about exchanging devices and about the possible device combinations is contained in the operating instructions or assembly instructions for the robot controller.

Procedure

1. Transfer the active project from the robot controller to WorkVisual.
(>>> 13.7 "Transferring a project from the robot controller to WorkVisual" Page 110)

 If settings have already been made in a project in WorkVisual which are to be transferred subsequently to the robot controller together with the controller bus configuration etc., then the active project must be transferred to WorkVisual using a comparison.
(>>> 13.8 "Comparing projects (and accepting differences)" Page 110)

2. Carry out the relevant configuration work.
(>>> 10.3 "Configuring the controller bus" Page 68)
(>>> 10.3.5 "Inserting the wagon driver configuration" Page 72)
(>>> 10.5 "Configuring further buses" Page 73)
3. If KUKA.ServoGun FC is used: Observe additional points.
(>>> 10.4 "Controller bus configuration for KUKA.ServoGun FC" Page 73)
4. Transfer the project to the robot controller and activate it there.
(>>> 13.4 "Transferring the project to the robot controller" Page 104)

10.2 Importing device description files (EtherCAT ESI)

Description

To be able to use a device in WorkVisual, WorkVisual requires the device description file for this device.

The device description files for the controller bus and the system bus are installed automatically during installation of WorkVisual. They are available in WorkVisual as soon as a catalog scan has been performed.



The procedure described here only needs to be carried out if device description files are obtained separately from KUKA for the controller bus or system bus.

Precondition

- There is no project open.

Procedure

1. Select the menu sequence **File > Import / Export**. The **Import/Export Wizard** window is opened.
2. Select **Import device description file** and click on **Next >**.
3. Click on **Browse...** and navigate to the directory where the files are located. Confirm with **Next >**.
4. A window opens. In the **File type** box, select the entry **EtherCAT ESI**.
5. Select the file to be imported and confirm with **Open**.
6. Click on **Finish**.
7. Close the **Import/Export Wizard** window.

10.3 Configuring the controller bus

10.3.1 Inserting (or removing) devices on the controller bus

Precondition

- Only if device description files have been obtained separately from KUKA: The files have been imported.
(>>> 10.2 "Importing device description files (EtherCAT ESI)" Page 67)
- The device description files have been inserted in the DTM Catalog.
(>>> 6.9 "Inserting the field bus master in the DTM Catalog (Catalog Scan)" Page 26)
- The robot controller has been set as the active controller.

Procedure

1. Right-click on the **Bus structure** node on the **Hardware** tab in the **Project structure** window.
2. Select **Add** from the context menu. The **DTM selection** window is opened.
3. Select the entry **KUKA Controller Bus** and confirm with **OK**. **KUKA Controller Bus** is inserted in the tree structure.
4. Right-click on **KUKA Controller Bus**.
5. Select **Add** from the context menu. The **DTM selection** window is opened.
6. Select the device used and confirm with **OK**. The device is inserted in the tree structure.
7. If required: Right-click on the device in the tree structure and select **Rename** from the context menu. Rename the device.
(>>> "Naming convention" Page 69)



The names that the devices have here in the bus structure are the names used in error messages.

8. Repeat steps 4 and 7 for all devices used in the real bus.
9. If a device needs to be removed from the bus: Right-click on the device and select **Delete** from the context menu.
10. Check the device settings and change if necessary.
(>>> 10.3.2 "Checking the device settings" Page 69)
11. Check the device connections and change if necessary.
(>>> 10.3.3 "Connecting devices on the controller bus" Page 70)
12. Only if the changes in the bus affect a KPP, or if the bus has been complete reconfigured: Insert the wagon driver configuration.

(>>> 10.3.5 "Inserting the wagon driver configuration" Page 72)




Fig. 10-1: Example of a controller bus



Arrange the devices in the **KUKA Controller Bus** node in the same order as they are arranged in reality.

The arrangement has no effect on its functionality of the bus, but it is easier to edit the connections on the **Topology** tab if the arrangement already corresponds to reality.

Naming convention

WorkVisual displays the device names that are defined in the device description files. In practice, other names are often used. For this purpose, the devices can be renamed.

In a bus, more than one device of the same type may be present. To distinguish them in the bus structure, WorkVisual automatically appends a number to the name. It is recommended, however, to give the devices meaningful names, e.g. by including the abbreviation for the installation position of the devices.

Name in WorkVisual	Usual name
KUKA Controller Bus (KCB)	[identical]
Cabinet Interface Board (CIB)	[identical]
Resolver Digital Converter (RDC)	[identical]
KUKA Power Pack 2 Axes (KPP2)	KUKA Power Pack 2 Axes (KPP2) (G1)
KUKA Servo Pack (KSP)	KUKA Servo Pack Wrist Axes (KSP) (T1) KUKA Servo Pack Main Axes (KSP) (T2)
KRC4 Electronic measuring tool (EMD)	Electronic Mastering Device (EMD)

10.3.2 Checking the device settings

Procedure

1. Right-click on the device on the **Hardware** tab in the **Project structure** window.
2. Select **Settings...** from the context menu. The **Settings...** window is opened.
3. Select the **General** tab.
4. Check that the following settings have been made. If not, correct the settings.
 - **Check vendor ID:** active

- **Check product code:** active
 - **Check revision number:** OFF
 - **Check serial number:** inactive
5. Close the window by clicking on **OK**.

The screenshot shows a software window with three tabs: 'General', 'Distributed clocks', and 'Process Data Objects'. The 'General' tab is active. It contains two main sections: 'Addresses' and 'Device identification'. In the 'Addresses' section, there are two input fields: 'EtherCAT address' with the value '1005' and 'EtherCAT alias' with the value '0'. In the 'Device identification' section, there are four checkboxes: 'Check vendor ID' (checked), 'Check product code' (checked), 'Check revision number' (set to 'OFF' in a dropdown menu), and 'Check serial number' (unchecked). Below these is a 'Serial number' input field with the value '0'.

Fig. 10-2: Device settings, “General” tab

10.3.3 Connecting devices on the controller bus

Description

If devices are inserted into the controller bus, WorkVisual connects the devices automatically. As WorkVisual does not know the real bus configuration, the connections must be checked and changed where necessary.



Information about the connector pin allocation of the devices can be found in the operating instructions for the robot controller.

Precondition

- All the devices used have been inserted into the **KUKA Controller Bus** node.

Procedure

1. Right-click on the **KUKA Controller Bus** node on the **Hardware** tab in the **Project structure** window.
2. Select **Settings...** from the context menu. The **Settings...** window is opened.
3. Select the **Topology** tab.
(>>> 10.3.4 “Topology” tab” Page 71)
4. Select and delete invalid connections. To do this, either press the Del key, or right-click and select **Delete**.
5. Insert missing connections. To do this, click on a connection and hold down the mouse button. Drag the mouse pointer to another connection and release the mouse button.
6. Mark temporary connections as such. To do this, right-click on the connection and select **Disconnectable** from the context menu. The connection is displayed as a broken line.
A temporary connection is e.g. the connection to the Electronic Mastering Device (EMD), because the EMD is not permanently connected.
7. Click on devices for which the address or alias address is not yet correct. A window appears. Enter the correct address.
All temporarily connected devices require an alias address. For the EMD, the alias address 2001 must be entered!
8. If required: Rearrange the devices using Drag&Drop. This serves to increase the clarity of the **Topology** tab. It has no effect on the bus.

9. Click on **OK** at bottom right.

10.3.4 “Topology” tab




Fig. 10-3: “Topology” tab

Properties of the “Topology” tab:

- Each device in the bus is represented by 1 rectangle.
- The numbers of the devices specify their physical address.
- **To display the name of a device:**
Move the mouse pointer onto the device. A tool tip is displayed with the name of the device.
Or alternatively, select the device. The window on the right displays the properties of this device, e.g. the name.

The devices in the figure:

Device	Name
1001	Cabinet Interface Board (CIB)
1002	Resolver Digital Converter (RDC)
1003	KUKA Power Pack 2 Axes (KPP2) (G1)
1004	KUKA Servo Pack Wrist Axes (KSP) (T1)
1005	KUKA Servo Pack Main Axes (KSP) (T2)
1006	Electronic Mastering Device (EMD)

- **To display the name of a connection:**
Move the mouse pointer onto the connection. A tool tip is displayed with the name of the connection.
- Lines shows the connections between the devices.
Solid lines indicate permanent connections. Broken lines indicate temporary connections.
- The devices can be reordered using Drag&Drop. This serves to increase the clarity of the **Topology** tab. It has no effect on the bus.

- The window on the right displays the properties of the selected device, e.g. the address and alias address. Some of the properties can be changed. All temporarily connected devices require an alias address. For the EMD, the alias address 2001 must be entered!
- The message area below the graphic shows if a device has an invalid address or alias address.

Editing connections:

- Select and delete invalid connections.
To do this, either press the Del key, or right-click and select **Delete**.
- Insert missing connections.
To do this, click on a connection and hold down the mouse button. Drag the mouse pointer to another connection and release the mouse button.
- Mark temporary connections as such.
To do this, right-click on the connection and select **Disconnectable** from the context menu. A temporary connection is e.g. the connection to the Electronic Mastering Device (EMD), because the EMD is not permanently connected.

10.3.5 Inserting the wagon driver configuration

Description

The wagon driver configuration must be inserted into the WorkVisual project in the following cases:

- If the controller bus has been completely reconfigured.
- Or if a change has been made to the controller bus which affects a KPP.
- If KUKA.ServoGun FC is used.

For this, the following configuration files are required:

- CFCoreWaggonDriverConfig.xml
- EAWaggonDriverConfig.xml

These files are automatically installed together with WorkVisual. These can be found in the directory C:\Program Files\KUKA\WorkVisual[...]\WaggonDriver-Configurations. They can be found there in the subdirectory for the relevant controller bus variant.

Which wagon driver configuration should be used for which controller bus?

Controller bus with ...	Directory
KPP without external axis	KPP 600-20
KPP with 1 external axis	KPP 600-20-1x40 (1x64)
KPP with 2 external axes	KPP 600-20-2x40
KPP with 1 external axis and ServoGun FC Sensor Box	KPP 600-20-1x40 + SDC
KPP with 2 external axes and ServoGun FC Sensor Box	KPP 600-20-2x40 + SDC
4-axis palletizer with external axis	4Ax_PA_mit_ZA
4-axis palletizer without external axis	4Ax_PA_ohne_ZA
5-axis palletizer with external axis	5Ax_PA_mit_ZA
5-axis palletizer without external axis	5Ax_PA_ohne_ZA
AGILUS sixx	6Ax_CIBsr_KPPsr_KSPsr

Precondition

- The robot controller has been set as the active controller.

Procedure

1. Expand the node of the robot controller on the **Files** tab in the **Project structure** window.
2. Then expand the following subordinate nodes: **Config > User > Common > Mada**.
3. Only if there are already wagon driver files in the **Mada** directory and these need to be removed:
 - Right-click on a file and select **Delete** from the context menu.
 - Repeat for the second file.
4. Right-click on the **Mada** folder and select **Add external file** from the context menu.




Fig. 10-4: Wagon driver configuration

5. A window opens. In the **File type** box, select the entry **All files (*.*)**.
6. Navigate to the directory in which the files for the wagon driver configuration are located, select the files and confirm with **Open**.
The files are now displayed in the tree structure below the **Mada** folder. (If not: collapse and expand all the folders in order to refresh the display.)

10.4 Controller bus configuration for KUKA.ServoGun FC

SDC topology

The SDC is connected to connection B of the RDC. The connection is a permanent connection (= not disconnectable).

10.5 Configuring further buses

The procedure is analogous to configuring the controller bus. Instead of **KUKA Controller Bus**, the following is inserted into the **Bus structure** node:

- **KUKA Extension Bus (SYS-X44)**
- **KUKA System Bus (SYS-X48)**

Which modules need to be inserted in the **KUKA Extension Bus (SYS-X44)** node depends on the specific bus structure in the real robot controller.

Which modules need to be inserted in the **KUKA System Bus (SYS-X48)** node also depends on the real bus structure. There is a maximum of 3 modules, however:

Module	Must be inserted in which case?
Safety module for Cabinet Interface Board (SION-CIB)	Must always be inserted.
Safety Interface Board SIB Standard (SION-SIB-STD)	Required if a Standard SIB is installed in the control cabinet.
Safety Interface Board SIB Extended (SION-SIB-EXT)	Required if an Extended SIB is installed in the control cabinet.

11 RoboTeam

i This documentation describes how RoboTeams can be configured offline with WorkVisual. Basic information about RobotTeam and about installation and programming on the robot controller can be found in the documentation **KUKA.RoboTeam**.

i The “RoboTeam” functionality is not available for projects with VKR C4 robot controllers.

11.1 Creating a RoboTeam

11.1.1 Creating a new RoboTeam project

Description WorkVisual provides templates which enable creation of a new project containing one or more RoboTeams. A wizard, the **Cell Configuration Wizard**, guides the user through the creation process.

Templates Templates for projects containing RoboTeams:

Template	Description
Generic project	Creates a project in which the number of RoboTeams and independent robots is specified by the user. The user also specifies the number of robots and external axes in each RoboTeam.
Simple RoboTeam project	Creates a project with 1 RoboTeam. The RoboTeam contains 2 robots and 1 external axis.
Project with two RoboTeams	Creates a project with 2 RoboTeams. Each RoboTeam contains 2 robots and 1 external axis. The project also contains a handling robot.




Fig. 11-1: Example screen: Cell Configuration Wizard

- Procedure**
1. Click on the **New...** button. The **Project Explorer** is opened. On the left, the **Create project** tab is selected.
 2. Select one of the templates for a RoboTeam project in the **Available templates** area of the tab.
 3. Enter a name for the project in the **File name** box.

4. The default directory for projects is given in the **Location** box. If required, select a different directory.
5. Click on the **New** button. The Cell Configuration Wizard opens.
6. Make the required settings in the wizard, e.g. select the robot type. Clicking on **Next** takes you to the next screen.
7. Once all the relevant settings have been made, click on **Finish** and then, in the next screen, on **Close**.
8. The robot network is now displayed on the **Hardware** tab of the **Project structure** window.




Fig. 11-2: Example: RoboTeam on the Hardware tab

11.1.2 Inserting a RoboTeam in an existing project

Description A RoboTeam can be inserted in an existing project.



If the RoboTeam is to be inserted in a new project, specific templates are available for project creation. This is quicker and easier than first creating an ordinary project and then inserting the RoboTeam.

(>>> 11.1.1 "Creating a new RoboTeam project" Page 75)

Precondition ■ The catalogs **KukaControllers** and **KUKARobots[...]** are available.

- If the RoboTeam is to contain external axes: The catalog **KukaExternalAxes** is available.

Procedure

1. Right-click on the node of the cell on the **Hardware** tab in the **Project structure** window and select the option **Add RoboTeam** from the context menu.

The node **Robot network** and the subnode **RoboTeam** are inserted. The nodes are numbered by default. They can be renamed.

2. Add the required number of robot controllers to the **RoboTeam** node.



It must always be the same robot controller that is added.

3. Assign robots to the robot controllers.
4. If required, assign external axes to the robot controllers.
5. If required, a further RoboTeam can be added to the network.

To do this, right-click on the **Robot network** node and select the option **Add RoboTeam** from the context menu. Then repeat steps 2 to 5.

11.2 Configuring the RoboTeam

11.2.1 Editors for the robot network and RoboTeam

RoboTeams and the associated network are configured using 2 different editors.

Precondition ■ At least 1 RoboTeam has been created.

Procedure **Open the editor for the robot network:**

1. Select the node **Robot network** on the **Hardware** tab in the **Project structure** window.
2. Double-click on the icon of the node.
Or select the menu sequence **Editors > Configure robot network**.

Procedure **Open the editor for the RoboTeam:**

1. Select the **Team** node on the **Hardware** tab in the **Project structure** window.
2. Double-click on the icon of the node.
Or select the menu sequence **Editors > Configure RoboTeam...**

Procedure **Rearranging elements in an editor:**

The user can move elements to achieve a clear arrangement of the elements. This has no effect on the configuration of the robot network or RoboTeam.

1. Right-click in the empty space in the editor and select **Select elements** from the context menu.
2. Click on an element and hold down the mouse button. The element can now be moved as desired.

Overview The editors display the following elements and information:

Robot network	RoboTeam
All robot controllers in the network	All kinematic systems in the team (robots and external axes)
The time master of the network	(Not displayed)
The safety master of each team	(Not displayed)
(Not displayed)	The motion master of the team
(Not displayed)	The workspaces
(Not displayed)	The access rights for the workspaces can be displayed.

Context menu The following functions are available in the context menu:

Icon	Name / description
	<p>Select elements</p> <p>Must be selected in order to move elements or to delete master/slave links.</p>
	<p>Define master/slave link</p> <p>In the editor for the robot network: Links individual RoboTeams to form a single safety circuit.</p> <p>(>>> 11.2.2 "Linking RoboTeams to form a single safety circuit" Page 78)</p> <p>In the editor for the RoboTeam: Defines the motion master(s).</p> <p>(>>> 11.2.4 "Defining the motion master" Page 80)</p>
	<p>Delete master/slave link</p> <p>(>>> 11.2.5 "Deleting a master/slave link" Page 81)</p>
	<p>Set time master</p> <p>Only available in the editor for the robot network. Defines the time master.</p> <p>(>>> 11.2.3 "Defining the time master" Page 79)</p>
	<p>Open help</p> <p>Calls the documentation for WorkVisual and displays the RoboTeam chapter.</p>

11.2.2 Linking RoboTeams to form a single safety circuit

Description

If a robot network comprises more than one RoboTeam, by default the individual teams form separate safety circuits. To group 2 or more teams into a single safety circuit, a link must be made from the safety master of one team to a robot controller of another team. This robot controller is now the safety master of the first team.

It is possible to integrate all the teams in a network into a single safety circuit.

The safety masters of the individual RoboTeams are defined automatically by WorkVisual and cannot be changed. They are indicated by gray arrows in the editor for the robot network: a gray arrow links each slave with the master.

Precondition

- The robot network contains more than 1 RoboTeam.
- The editor for the robot network is open.

Procedure

1. Right-click in the empty space in the editor and select **Define master/slave link** from the context menu.
2. Click on the safety master of a team and hold down the mouse button.
3. Drag the mouse pointer to the robot controller of another team and release the mouse button.

The robot controller of the other team is now the safety master of the first team. This is shown in the editor by a black arrow.

Any previous link with another team is automatically deleted by the new one.




Fig. 11-3: Display of safety masters / safety circuits

Item	Description
1	Controller 1 is the safety master of team 1 (cannot be influenced by the user)
2	With this arrow, the user has linked team 1 and team 2 to form one safety circuit. Alternative: an arrow from controller 3 to controller 1
3	Controller 3 is the safety master of team 2 (cannot be influenced by the user)

11.2.3 Defining the time master

Description After a robot network has been created, the message window displays which robot controller has been defined as the time master by WorkVisual. This assignment can be changed.

In the editor for the robot network, the time master is indicated by a small analog clock icon. There can be only 1 time master per network.

On the real robot controller, the time master is not visible and cannot be changed.

Precondition ■ The editor for the robot network is open.

Procedure

1. Right-click in the empty space in the editor and select **Set time master** from the context menu.
2. Click on the robot controller that is to be set as the new time master.
The new time master is now indicated in the editor by the analog clock icon. The clock has now disappeared from the previous time master.




Fig. 11-4: Display of the time master

Item	Description
1	The clock indicates the time master.

11.2.4 Defining the motion master

Description

This procedure is used to define which kinematic system should be able to follow the motions of another kinematic system. The second kinematic system is then the motion master. This procedure therefore does not define which kinematic systems actually follow the motions of others, but merely which possibilities should apply. Only those kinematic systems that have been defined here in WorkVisual as master and/or slave can be used as such in the program.

Multiple connections and bidirectional connections are possible, as kinematic systems may be motion master and slave simultaneously.

Multiple connections between 2 kinematic systems in the same direction are not possible.



It is advisable to create only those connections which are actually required in the program. Do not connect every kinematic system to every other kinematic system in both directions, as this would take up TOOL and BASE coordinate systems unnecessarily. These would then be unavailable for other purposes.

Precondition

- The editor for the RoboTeam is open.

Procedure

1. Right-click in the empty space in the editor and select **Define master/slave link** from the context menu.
2. Click on a kinematic system (robot or external axis) and hold down the mouse button.

3. Drag the mouse pointer to another kinematic system and release the mouse button.
The first kinematic system can now follow the other kinematic system. This is shown in the editor by a black arrow.
4. Repeat steps 2 and 3 until every kinematic system is connected to at least one other kinematic system.

If there are still unconnected kinematic systems, the following error message is displayed on closing the editor: *Configuration of Motion Cooperation for [RoboTeam_name] is not complete!*




Fig. 11-5: Display of the motion master

Item	Description
1	KR 60-3 2 is the motion master of KR 60-3 1.
2	KL 250 1 is the motion master of KR 60-3 2. The arrow is orange instead of black because the mouse pointer is positioned on it.
3	Positioning the mouse pointer on an arrow opens an info box. Only for projects transferred to WorkVisual from a robot controller: This displays the translation values of the slave relative to the WORLD coordinate system of the master.

11.2.5 Deleting a master/slave link

Description If the link between a safety master and another team is to be changed, the existing link does not need to be deleted separately, as this happens automatically when a new link is established.

Links which define motion masters, however, do have to be deleted if they are no longer needed.

- Procedure**
1. Right-click in the empty space in the editor and select **Select elements** from the context menu.
 2. Click on the arrow to be deleted. The color of the arrow changes to blue.
 3. Right-click and select **Delete master/slave link** from the context menu. The arrow is deleted.

11.2.6 Creating and configuring workspaces

Description

i The workspaces described here are specific to RoboTeam and have nothing to do with the following workspaces:

- Workspaces configured in the KUKA System Software via **Configuration > Extras > Workspace monitoring > Configuration**.
- Workspaces configured in SafeOperation.

No workspaces can be created or configured for RoboTeam on the real robot controller.

Precondition

- The RoboTeam has been created.
- The editor for the RoboTeam is open.

Procedure

1. The editor for the RoboTeam, click on **Add** in the **Definition of the workspaces** area.
2. A workspace is inserted. The default name is **Semaphor** [*consecutive no.*]. The default name can be changed:
 - a. Click on the name. The name can now be edited.
 - b. Change the name and confirm with the Enter key.
3. A robot controller is defined as the workspace master. The workspace master can be changed:
 - a. Click on the name displayed next to the **Master** box.
 - b. The robot controllers of the team are displayed. Click on the desired robot controller.
4. To configure the access rights to the workspace, click on the **Devices** button. A window opens.
5. Define the rights as required. (>>> "Access rights" Page 83)

Workspaces




Fig. 11-6: Display of the workspaces

Item	Description
1	Display of the workspaces If there is more than one workspace, the highest workspace (no. 1) has the highest priority and the lowest workspace has the lowest priority.
2	The defines whether the status of the workspaces is restored after a cold start of the robot controller. <ul style="list-style-type: none"> ■ Restore Workspaces On: The status is not restored. Clicking on the button activates the “Restore status” function. ■ Restore Workspaces Off: The status is restored. Clicking on the button deactivates the “Restore status” function.

Access rights




Fig. 11-7: Configuring access rights

Item	Description
1	Displays the robot controllers which may not access the workspace. RIGHT ARROW moves the selected robot controllers into the Devices area.
2	Displays the robot controllers which may access the workspace. Only 1 robot controller can access a workspace at a time. Note: The arrangement of the robot controllers in the display does not reflect the order in which they access the workspace. This order is determined solely by the KRL program. LEFT ARROW moves the selected robot controllers into the Controllers area.

11.3 Preventing data loss in RoboTeam projects

Description

If changes have been made on the real RoboTeam controllers which have not been made in WorkVisual (e.g. calibrating tools), these changes are lost if the RoboTeam project is transferred from WorkVisual to the robot controllers.

If changes are made to a RoboTeam project in WorkVisual without the current states of the real robot controllers having been updated, data can also be lost subsequently during transfer.

Procedure

- This data loss can be prevented by transferring the current states of all the real robot controllers to WorkVisual after opening and before editing a project.

(>>> 13.8 "Comparing projects (and accepting differences)" Page 110)

To remind the user of this, the following warning message is displayed after a RoboTeam project is opened: **This project contains at least one RoboTeam. To avoid data loss, please carry out a project merge with all involved controllers.**

11.4 Transferring a RoboTeam project to the robot controller

Procedure

The procedure is the same as for ordinary projects.

(>>> 13.4 "Transferring the project to the robot controller" Page 104)

The following must be observed when transferring RoboTeam projects to a robot controller for the first time:

- To complete the project, select the active project on the real robot controller.
- Completely transfer the state of the real robot controller. For this, activate the check box for every robot controller in the **Selected value** column.

⚠ WARNING When activating a project on the KUKA smartHMI, an overview is displayed of the changes which will be made in comparison to the project that is still active on the robot controller. If changes are listed in the overview under the heading **Safety-relevant communication parameters**, this means that the behavior of the Emergency Stop and "Operator safety" signal may have changed compared with the previous project. After activation of the project, the Emergency Stop and the "Operator safety" signal must be checked for safe functioning. If the project is activated on several robot controllers, this check must be carried out for every robot controller. Failure to carry out this check may result in death to persons, severe physical injuries or considerable damage to property.

Example: Complete

In this example, a RoboTeam project containing 2 robot controllers is completed. The check box has been activated for both robot controllers in the **Selected value** column. The check boxes for the subordinate elements are activated automatically.




Fig. 11-8: Example: Completely transferring the state of the real robot controller

Item	Description
1	Check mark for robot controller 1
2	Check mark for robot controller 2

12 Programming

12.1 Creating a program

- Precondition**
- With use of a KR C4 controller: the **KRL Templates** catalog has been inserted in the **Catalogs** window.
 - With use of a VKR C4 controller: the **VW Templates** catalog has been inserted in the **Catalogs** window.
- Procedure**
1. Expand the tree structure of the robot controller on the **Files** tab in the **Project structure** window.
 2. Right-click on the node in which the program is to be created and select **Add...** from the context menu. The catalog **KRL Templates** or **VW Templates** is opened.
 3. Select the desired template and confirm with **Add**. The program file is inserted in the tree structure.
The file can now be edited with the KRL Editor.
- Alternative procedure**
1. Expand the tree structure of the robot controller on the **Files** tab in the **Project structure** window.
 2. Select the required template in the **KRL Templates** or **VW Templates** catalog and drag it onto a node in the tree structure. The program file is inserted in the tree structure.
The file can now be edited with the KRL Editor.

12.2 Importing a program

- Description** Files in the formats SRC, DAT, SUB and KRL can be imported.
- Procedure**
1. Expand the tree structure of the robot controller on the **Files** tab in the **Project structure** window.
 2. Right-click on the node in which the program is to be created and select **Add external file** from the context menu.
 3. Navigate to the directory where the file is located that is to be imported.
 4. Select the file and confirm with **Open**. The file is inserted in the tree structure.
The file can now be edited with the KRL Editor.

12.3 Displaying the variable declarations in a file

All the KRL variables that are declared in a particular file can be displayed in a list overview. With SRC files, the variables from the corresponding DAT file are always displayed at the same time, and vice versa.

- Procedure**
1. Only if the **Variable list** window is not yet displayed: Display it by selecting the menu sequence **Window > Variable list**.
 2. In the **Variable list** window, set the required update behavior using the buttons. (Update via the **Files** tab and/or via the KRL Editor.)
 3. Press the **Refresh** button.
This step can be skipped if no changes have been made since WorkVisual was last opened or since **Refresh** was last carried out on the **Files** tab.
 4. Select the file on the **Files** tab in the **Project structure** window.
Or: Open the file in the KRL Editor, or, if it is already open, click on the tab for the file.
 5. The variable list now displays all the variables that are declared in this file.

6. If necessary, a variable can be selected in the KRL Editor as follows (if the KRL Editor is not yet open, this causes it to open):
 - Double-click on the line in the search results.
 - Or: Right-click on the line and select **Go to...** from the context menu.
 - Or: Select the line and press the Enter key.

A search function is available in the **Variable list** window, which allows a search to be carried out within the current file:


- Enter the variable name or part of the name in the search box. The search results are displayed immediately.

If the cursor is positioned in the **Variable list** window, CTRL+F can be used to jump to the search box.

If the cursor is positioned in the search box, this can be emptied by pressing ESC.

 If the search box contains a search term, this remains valid if the focus is moved to another file. It is only possible to display all the variables in a file if the search box is empty.

Description



Name	Type	line / column	Filename	Scope
SUCCESS	INT	5 / 9	Modul.dat	lokal
my_var	INT	11 / 13	Modul.dat	lokal

Fig. 12-1: “Variable list” window

Clicking on a column sorts the list by this column.

Button	Description
	Refresh All the files on the Files tab in the Project structure window are refreshed. Globally valid variables and references between the files are updated.
	Button is pressed: If a file is selected on the Files tab in the Project structure window, the variable list is updated. Button is not pressed: If a file is selected on the Files tab, the variable list does not change.
	Button is pressed: The variable list is updated if the tab of a file is selected in the KRL Editor. Button is not pressed: If the tab of a file is selected in the KRL Editor, the variable list does not change.
	Button is pressed: The display is sorted by file type. (Within this sort mode, it is also possible to sort by column.) Button is not pressed: The display is not sorted by file type.
	Button is pressed: The search includes all global variables. Button is not pressed: The search refers to all local variables of the current file.

12.4 KRL Editor

12.4.1 Opening a file in the KRL Editor

Precondition

- This is a file format that can be edited with the KRL Editor.
(>>> "File formats" Page 89)

Procedure

1. Double-click on a file on the **Files** tab in the **Project structure** window.
Or: Select the file and select the menu sequence **Editors > KRL Editor**.
2. To close the file: Click on the "X" at top right.

The KRL Editor allows more than one file to be open simultaneously. If required, they can be displayed side by side or one above the other. This provides a convenient way of comparing contents, for example.

To display the files side by side:

1. Right-click in the title bar of the file in the KRL Editor. Select **New Vertical Tab Group** from the context menu.
2. To display the files one behind the other again: Right-click in the title bar of a file in the KRL Editor. Select **Move Next** or **Move Previous** from the context menu.

To display the files one above the other:

1. Right-click in the title bar of the file in the KRL Editor. Select **New Horizontal Tab Group** from the context menu.
2. To display the files one behind the other again: Right-click in the title bar of a file in the KRL Editor. Select **Move Next** or **Move Previous** from the context menu.

File formats The KRL Editor is used primarily to edit files containing KRL code:

- SRC
- DAT
- SUB

In addition, the KRL Editor can be used to edit the following file formats:

- ADD
- BAT
- CONFIG
- CMD
- DEL
- INI
- KFD
- KXR
- LOG
- REG
- TXT
- XML

12.4.2 KRL Editor user interface




Fig. 12-2: KRL Editor user interface

Item	Description
1	<p>Program area</p> <p>The code is entered and edited here. The KRL Editor provides numerous functions to support the programmer with this.</p>
2	<p>List of the subprograms in this file</p> <p>To go to a subprogram, select it from the list: the cursor then jumps to the DEF line of this subprogram.</p>
3	<p>List of variable declarations</p> <p>This list always refers to the subprogram that is currently selected in the list of subprograms. To go to a declaration, select the variable from the list: the cursor then jumps to the line containing the declaration of these variables.</p>
4	<p>Analysis bar</p> <p>The marks indicate errors or discrepancies in the code.</p> <ul style="list-style-type: none"> ■ Hovering with the mouse over a mark displays a tool tip with a description of the error. ■ Clicking on the mark makes the cursor jump to the relevant place in the program. An automatic correction is offered for some errors/discrepancies. <p>(>>> 12.4.8 "Quickfix correction" Page 94)</p>
5	<p>The square has the color of the most serious error currently present.</p> <p>If there are no errors/discrepancies, the square is green.</p>

12.4.3 Zooming in/out

Procedure

1. Click anywhere in the KRL Editor.

2. Hold down the CTRL key and move the mouse wheel.
 - Mouse wheel up: zoom in
 - Mouse wheel up: zoom out

12.4.4 Configuring the KRL Editor

Preparation Only necessary if it is desirable to see a preview of the effect of the settings:

1. Open a file in the KRL Editor.
2. To see a preview of the colors for the marks: select any point in the file. (Nothing can be selected in the file while the **Options** window is open.)

Procedure

1. Select the menu sequence **Extras > Options**. The **Options** window is opened.
2. If no subitems are visible under the **Text editor** folder, double-click on the folder to reveal these.
3. Select a subitem. The configuration options for this subitem are displayed in the right-hand section of the window.

 If the mouse pointer is moved over a field, a description is displayed for this field at the bottom of the window.

4. Make the desired changes.

The changes can be seen immediately if a file is currently open in the KRL Editor (e.g. if spaces are revealed or hidden).
5. Click on **OK** to confirm. The changes are saved.

Or discard the changes with **Cancel**.

The color settings can be reset to the default settings at any time. The **Reset** button for this is situated on the corresponding page in the **Options** window. (At the bottom of the page; scrolling is required.)

12.4.5 Edit functions

12.4.5.1 General edit functions

Select

- Selecting an area: click where the selection should begin and hold down the left-hand mouse button. Drag the mouse until the desired area is selected, and then release the mouse button.

 If the ALT key is additionally held down during selection, it is possible to select a rectangular area.

- To select a line: click on the line number.

Edit Standard edit functions can be called via the context menu. These include:

- **Cut, Paste, Copy, Delete**
- **Undo, Redo**
- **Find ...**

In addition, the following commands are available in the context menu.

 ■ Not all commands are available for every file format.
 ■ Commands which refer to a selected area affect the whole file if no area is selected.

Menu item	Description
Edit > Make upper case	Converts all the lower-case letters in the selected string into upper-case letters.
Edit > Make lower case	Converts all the upper-case letters in the selected string into lower-case letters.
Edit > Title case	Converts all the initial letters in the selected string into upper-case letters.
Edit > Convert tabs into spaces	Replaces the tabs in the selected string with spaces. Note: The number of spaces corresponding to one tab can be configured in the parameter Indent size .
Edit > Convert spaces into tabs	Replaces the spaces in the selected string with tabs.
Edit > Indent	Inserts additional spaces at the beginning of every line in the selected area. Note: The number of spaces inserted can be configured in the parameter Indent size .
Edit > Remove leading whitespace	Removes all the leading spaces from the lines in the selected area.
Folds > Expand all	Opens all folds in the currently displayed file.
Folds > Collapse all	Closes all folds in the currently displayed file.
Format	Indentations, line breaks, etc., are adapted throughout the file to conform to the standard. The applicable standard depends on the file format.
Comment selection	Uncomments the line.
Uncomment selection	Comments the line out.
Rename	(>>> 12.4.5.2 "Renaming variables" Page 92)
Go to declaration	(>>> 12.4.7 "Jumping to the declaration of a variable" Page 94)
Insert snippet	(>>> 12.4.5.4 "Snippets – Fast entry of KRL instructions" Page 93)

12.4.5.2 Renaming variables

Description A variable name can be changed in a single action at all points where it occurs. This is also possible if the variable is declared in a DAT file and used in various SRC files.

Procedure

1. Select the desired variable at any point.
2. Press F11.
Or: Right-click and select **Rename** from the context menu.
3. A window opens. Change the name and confirm with **OK**.

12.4.5.3 Auto-complete

An auto-complete function is available in the KRL Editor.

When entering code, a list containing the following elements is displayed automatically:

- KRL keywords
- Known variable names
- Known function names
- Known user-specific data types (STRUC or ENUM)

- Snippets (>>> 12.4.5.4 "Snippets – Fast entry of KRL instructions" Page 93)

Those elements that are compatible with the characters already entered are shown at the top of the list. These elements are also prioritized according to their frequency of use, i.e. the selection is dynamically adapted to the user's actions.

If required, an element in the list can be selected and inserted in the program text using the Enter key. This makes it unnecessary to type complex variable names, for example.



Navigation in the "Auto-complete" list:

- Scroll
- Or: Type the first letter of the desired element. The marker jumps to the relevant position.

12.4.5.4 Snippets – Fast entry of KRL instructions

Description A fast entry function is available in the KRL Editor for common KRL instructions.

To program a FOR loop, for example, it is not necessary to enter the entire syntax FOR ... = ... TO ... STEP Instead, the instruction can be selected from the "Auto-complete" list. All that is then required is to fill out the variable positions in the syntax manually.

Procedure On starting to type the code, the "Auto-complete" list is shown. The required instruction is generally already selected.

1. Accept the selected instruction from the "Auto-complete" list using the Enter key. Or double-click on a different instruction.




Fig. 12-3: Accept with the Enter key, or double-click

2. The KRL syntax is inserted automatically. The first variable position is highlighted in blue. Enter the desired value.




Fig. 12-4: The first variable position is highlighted in blue

3. Press the TAB key to jump to the next variable position. Enter the desired value.
4. Repeat step 3 for all other variable positions.
5. To finish editing, press the Enter key.

The snippet list can also be called separately: Right-click and select **Insert snippet** from the context menu.

It is also possible to enter a snippet as follows: Type in the abbreviation and press the TAB key.

(The abbreviation can be determined by calling the snippet list. Select the instruction. A tool tip is displayed. The 2nd line contains the possible abbreviations.)

12.4.6 Folds

Description

The content of the KRL Editor can be structured with folds just like any normal KRL program.



Fig. 12-5: Closed fold




Fig. 12-6: Opened fold

Procedure

To open a fold:

- Double-click on the box of the closed fold.
- Or: Click on the plus sign.

To close a fold:

- Click on the minus sign.

To open or close all folds:

- Context menu: **Folds > Expand all** or **Collapse all**

12.4.7 Jumping to the declaration of a variable

Procedure

1. Place the cursor in the variable name, or directly in front of the first letter or directly after the last letter.
2. Press F12.
Or: Right-click and select **Go to declaration** from the context menu.

12.4.8 Quickfix correction

Wavy red lines in the code and marks in the analysis bar indicate errors or discrepancies in the code.

For some of these errors/discrepancies, an automatic correction function – the “Quickfix” – is offered. A Quickfix light bulb is displayed. Via the arrow button

next to the light bulb, the user can display various possible solutions and select one.



Fig. 12-7: Quickfix light bulb

12.4.8.1 Correcting or automatically declaring undeclared variables

Description

Undeclared variables are displayed as follows:

- With a wavy red line in the code
- With a red mark in the analysis bar

The red color can also refer to a different error, however. If it refers to an undeclared variable, the following tool tip is displayed if you hover with the mouse over the wavy line or mark: *The declaration of variable [name] was not found.*

Procedure

1. Place the cursor in the name underlined with the wavy line, or directly in front of the first letter or directly after the last letter.
Or: Click on the mark in the analysis bar.
The Quickfix light bulb is now displayed next to the variable name.
2. Check if the variable name has been written incorrectly (differently from in the declaration).
 - If so: correct. The wavy red line / mark disappears. No further steps are necessary.
 - If not: continue with the next step.
3. Move the mouse pointer onto the Quickfix light bulb. An arrow is displayed next to the light bulb.
Click on the arrow. The following options are displayed:
 - *Declare the variable locally*
 - *Declare the variable in the data list*
4. Click on the desired option.
5. Only with *Declare the variable in the data list*: The data list is opened.
Open the fold BASISTECH EXT.
6. A snippet for the variable declaration has been automatically inserted. The expected data type is highlighted in blue. The declaration is followed by the comment: *; This variable is for*
 - Accept or change the data type, as required.
 - Press the TAB key to jump to the comment. Edit the comment if required.



This comment is displayed in the tool tip of the "Auto-complete" list if the variable is selected there.

12.4.8.2 Removing unused variables

Description

Unused variables are displayed as follows:

- With a wavy blue line in the code
- With a blue mark in the analysis bar

Hovering with the mouse over the wavy line or mark displays a tool tip with a description.

Procedure

1. Place the cursor in the name underlined with the wavy line, or directly in front of the first letter or directly after the last letter.
Or: Click on the mark in the analysis bar.
The Quickfix light bulb is now displayed next to the variable name.
2. Move the mouse pointer onto the Quickfix light bulb. An arrow is displayed next to the light bulb.
Click on the arrow. The following options are displayed:
 - *Remove declaration*
 - *Comment out declaration*
3. Click on the desired option.

12.4.8.3 Standardizing the upper/lower case in a variable name**Description**

If the use of upper/lower case in a variable name is not uniform in the declaration and in its other occurrences, this is displayed as follows:

- With a light blue wavy line in the code
- With a light blue mark in the analysis bar

Hovering with the mouse over the wavy line or mark displays a tool tip with a description.

Procedure

1. Place the cursor in the name underlined with the wavy line, or directly in front of the first letter or directly after the last letter.
Or: Click on the mark in the analysis bar.
The Quickfix light bulb is now displayed next to the variable name.
2. Move the mouse pointer onto the Quickfix light bulb. An arrow is displayed next to the light bulb.
Click on the arrow. The following options are displayed:
 - *Change this use to [name as in declaration]*
 - *Change declaration to [name as at this point in the program]*
3. Click on the desired option.

12.4.9 Creating user-specific snippets**Description**

Users can create their own snippets. For this, the required properties must be saved in a file with the SNIPPET format. This file must then be imported in WorkVisual. The snippet is then available in the KRL Editor.

A template for a SNIPPET file is provided on the WorkVisual CD in the DOC directory.

Procedure

Once the SNIPPET file has been created, it must be imported as follows:

1. Select the menu sequence **Extras > Import snippet from file** A window opens.
2. Navigate to the directory where the SNIPPET file is located and select it.
Click on **Open**.
The snippet is now available in the KRL Editor.

Example 1

A snippet is to be created to insert the following code structure:

```
MYTHING true
ENDTHING
```

Fig. 12-8: Code to be inserted by the snippet

The snippet is to have the name “User” in the snippet list, and the tool tip should contain the information shown here:




Fig. 12-9: Desired snippet

The SNIPPET file must have the following format:

```

2 <CodeSnippets>
3 <CodeSnippet Format="1.0.0">
4 <Header>
5
6 <!--Is displayed as header in the static ToolTip(on the right side) of the completion window-->
7 <Title>User-Snippet</Title>
8
9 <!--Is displayed in the completion window-->
10 <Text>User</Text>
11
12 <!--These shortcuts can be used-->
13 <Shortcut>usr</Shortcut>
14 <Shortcut>USR</Shortcut>
15 <Shortcut>Usr</Shortcut>
16
17 <!--For these file extensions the snippet will be shown -->
18 <Extensions>.src .sub</Extensions>
19
20 <!--Is displayed as description in the static ToolTip(on the right side) of the completion window-->
21 <Description>my description for my snippet</Description>
22
23 <!--Is displayed as author in the static ToolTip(on the right side) of the completion window-->
24 <Author>my Name</Author>
25
26 <!--Specifies the type of the snippet-->
27 <SnippetTypes>
28 <SnippetType>Expansion</SnippetType>
29 <SnippetType>SurroundsWith</SnippetType>
30 </SnippetTypes>
31 </Header>
32
33 <FileExtensions/>
34 <Snippet>
35 <Declarations>
36 <Literal>
37 <ID>element</ID>
38 <ToolTip>my tooltip for this element</ToolTip>
39 <Default>true</Default>
40 </Literal>
41 </Declarations>
42 <Code Language="KRL">
43 <![CDATA[MYTHING $element$
44 $end$$selection$
45 ENDTHING]]>
46 </Code>
47 </Snippet>
48 </CodeSnippet>
49 </CodeSnippets>

```

Fig. 12-10: Structure of the SNIPPET file

Line	Description
3 ... 48	Section for 1 snippet A SNIPPET file may contain a number of these sections, i.e. a number of different snippets.
7	Title displayed in the tool tip
10	Name displayed in the snippet list Note: The “Auto-complete” function reacts to this character string, i.e. if this string is entered in the program, the “Auto-complete” list is shown and the corresponding snippet is selected.
13 ... 15	Shortcuts for this snippet
18	The snippet is only displayed in the list in files with this extension
21	Description displayed in the tool tip
24	Name of the author displayed in the tool tip
27 ... 30	This defines the ways in which the snippet can be inserted. <ul style="list-style-type: none"> ■ Expansion: The snippet is inserted at the current cursor position. ■ SurroundsWith: Before the snippet is inserted, program lines can be selected in the KRL Editor. The snippet is then automatically inserted so that it surrounds these lines. The exact position of these lines within the snippet is defined by the placeholder \$selection\$.
37	Placeholder occurring in lines 43 ... 45, to which lines 38 and 39 refer
38	Tool tip displayed for this placeholder
39	Default value for the placeholder
43 ... 45	Program text inserted by the snippet The text consists of hard text and/or placeholders. <ul style="list-style-type: none"> ■ \$selection\$: See description for SurroundsWith. ■ \$end\$: This placeholder defines the position of the cursor after insertion of the snippet has been completed with the Enter key.

Example 2

An example of the <Snippet> section only:

```
FOR counter = start TO stop STEP 1
ENDFOR
```

Fig. 12-11: Code inserted by the snippet

```

18 <Snippet>
19   <Declarations>
20     <Literal>
21       <ID>counter</ID>
22       <ToolTip>Counter variable, has to be declared</ToolTip>
23       <Default>counter</Default>
24     </Literal>
25     <Literal>
26       <ID>start</ID>
27       <ToolTip>start value for counter</ToolTip>
28       <Default>start</Default>
29     </Literal>
30     <Literal>
31       <ID>stop</ID>
32       <ToolTip>value for loop to stop</ToolTip>
33       <Default>stop</Default>
34     </Literal>
35     <Literal>
36       <ID>step</ID>
37       <ToolTip>step width for counter</ToolTip>
38       <Default>1</Default>
39     </Literal>
40   </Declarations>
41   <Code Language="KRL">
42     <![CDATA[FOR $counter$ = $start$ TO $stop$ STEP $step$
43 $selection$$end$
44 ENDFOR]]>
45   </Code>
46 </Snippet>

```

Fig. 12-12: Structure of the SNIPPET file

13 Transferring and activating the project

13.1 Generating code

Description

When a project is transferred to the robot controller, the code is always generated first. This procedure can be used to generate the code separately and thus to check in advance whether generation runs without error.

The code is displayed on the **Files** tab of the **Project structure** window.

Automatically generated code is displayed in pale gray.




Fig. 13-1: Example of code generation: before – after

Procedure

- Select the menu sequence **Extras > Generate code**.

The code is generated. When the process is finished, the following messages are displayed in the message window: **The project <"{0}" V{1}> has been compiled. The results can be seen in the file tree.**

13.2 Pinning a project

Description

Projects that are present on the robot controller can be pinned. A project can be pinned directly on the robot controller or in WorkVisual.

Pinned projects cannot be changed, activated or deleted. They can be copied or unpinned, however. A project can thus be pinned e.g. to prevent it from being accidentally deleted.

Procedure

Pinning in WorkVisual:

1. Select the menu sequence: **File > Browse for project**. The **Project Explorer** is opened. On the left, the **Search** tab is selected.
2. In the **Available cells** area, expand the node of the desired cell. All the robot controllers of this cell are displayed.
3. Expand the node of the desired robot controller. All projects are displayed. Pinned projects are indicated by a pin symbol.
4. Select the desired project and click on the **Pin project** button. The project is pinned and labeled with a pin symbol in the project list.



Information about pinning on the robot controller can be found in the **Operating and Programming Instructions for System Integrators** for the KUKA System Software.

13.3 Assigning the robot controller to the real robot controller

Description This procedure is used to assign every robot controller in the project to a real robot controller. The project can then be transferred from WorkVisual to the real robot controller.

Precondition

- A robot controller has been added in WorkVisual.
- Network connection to the real robot controller
- The real robot controller and the KUKA smartHMI are running.

If the project is subsequently to be transferred and also activated:

- The user group “Expert” or higher is selected on the real robot controller. Restriction: If the activation would cause changes in the area **Safety-relevant communication parameters**, the user group “Safety recovery” or higher must be selected.
- If the operating mode AUT or AUT EXT is selected on the real robot controller: The project contains only settings that affect KRL programs. If the project contains settings that would cause other changes, it cannot be activated.

Procedure

1. Click on the **Deploy...** button in the menu bar. The **Project deployment** window is opened.
2. The available cells are displayed under **Target cell**. (The cells can be renamed by right-clicking.)
If the desired cell is not displayed, a new cell can be created:
 - Click on **New cell**. The **Cell properties** window opens. Enter a name and, if required, a description. Press **OK** to save.
The new cell is now shown under **Target cell**.
3. Select the desired cell under **Target cell**. This cell must now be assigned to the real robot controller.
4. Select the desired real robot controller under **Available controllers**.
Depending on the network topology, it is possible that the robot controller may not be displayed under **Available controllers**. If the IP address is known, the robot controller can be displayed as follows:
 - Click on . A window opens. Enter the IP address and confirm with **OK**.
The robot controller is now shown under **Available controllers**.




Fig. 13-2: Assigning the robot controller to the cell

5. Click on . The robot controller is now shown under **Target controllers**.
6. If the project contain more than one robot controller, repeat steps 4 and 5 for the other robot controllers.
7. The virtual robot controller must now be assigned to the real robot controller: Click on **Next**.

 Each virtual robot controller must be assigned to exactly one real robot controller.

8. Select the virtual controller under **Controllers in the project**.
9. Under **Controllers in the cell**, select the real robot controller and click on . The real robot controller is assigned to the virtual robot controller.




Fig. 13-3: Assigning a real robot controller to the virtual controller

10. If the project contain more than one robot controller, repeat steps 8 and 9 for the other robot controllers.

11. Click on **Next**. An overview is displayed. (Here it is still possible to change the assignment if necessary. To do this, click on **Change ...**)




Fig. 13-4: Overview

12. The project can now be transferred to the robot controller.
 (>>> 13.4 "Transferring the project to the robot controller" Page 104)
 Alternatively, the project can be transferred at a later point in time. To do this, click on **Cancel**: the assignment is saved and the **Project deployment** window is closed.

13.4 Transferring the project to the robot controller

Description

This procedure is used to transfer the project from WorkVisual to the real robot controller.

This section describes the procedure for transferring a project to a real robot controller with KUKA System Software/ VW System Software 8.2.



If a project was transferred to the real robot controller at an earlier time and has not yet been activated then this will be overwritten if a further project is transferred.

Transferring and activating a project overwrites a project of the same name that already exists on the real robot controller (after a request for confirmation).

Precondition

- The project has been assigned to the real robot controller.
- Network connection to the real robot controller
- The real robot controller and the KUKA smartHMI are running.

If the project is also to be activated:

- The user group "Expert" or higher is selected on the real robot controller.
 Restriction: If the activation would cause changes in the area **Safety-relevant communication parameters**, the user group "Safety recovery" or higher must be selected.
- If the operating mode AUT or AUT EXT is selected on the real robot controller: The project contains only settings that affect KRL programs. If the project contains settings that would cause other changes, it cannot be activated.

i If one of the options KUKA.SafeOperation or KUKA.SafeRangeMonitoring is installed on the robot controller, different user groups may apply. Information can be found in the documentation for these options.

i If a project is transferred containing an option package that has not yet been installed on the robot controller, then the procedure differs from the normal one. The following procedure must be observed:

1. Transfer the project to the robot controller, but DO NOT activate it!
2. Install the option package on the robot controller.
Installation is performed in the normal manner. Information about this can be found in the option package documentation or in the operating and programming instructions for the KUKA System Software (KSS).
3. Transfer the project back to WorkVisual using the comparison method, accepting the status as on the robot controller.
(>>> 13.8 "Comparing projects (and accepting differences)" Page 110)
4. Transfer the project back to the robot controller.
5. Activate the project on the robot controller.

Procedure

1. Click on the **Deploy...** button in the menu bar. The **Project deployment** window is opened.




Fig. 13-5: Overview with warning about incomplete configuration

2. If the project has never been transferred back to WorkVisual from a robot controller before, it will not yet contain all the configuration files. This is indicated by a message. (The configuration files include machine data files, safety configuration files and many others.)
 - If this message is not displayed: Continue with step 13.
 - If this message is displayed: Continue with step 3.
3. Click on **Complete**. The following confirmation prompt is displayed: **The project must be saved and the active controller will be reset! Do you want to continue?**
4. Answer the query with **Yes**. The **Merge projects** window is opened.




Fig. 13-6: Selecting a project for “Complete”

5. Select a project from which the configuration data are to be transferred, e.g. the active project on the real robot controller.

i If a RoboTeam project is being transferred to the robot controller, always select the active project.

6. Click on **Next**. A progress bar is displayed. (If the project contains more than one controller, a bar is displayed for each one.)
(>>> "Progress bars" Page 112)
7. When the progress bar is full and the message **Status: Ready for merge** is displayed: Click on **Show differences**.
The differences between the projects are displayed in an overview.
(>>> "Comparison" Page 112)
8. For each difference, select which state to accept. This does not have to be done for all the differences at one go.
If suitable, the default selection can also be accepted.

i If a RoboTeam project is being transferred to the robot controller for the first time, accept the complete state of the real robot controller. For this, activate the check box for every robot controller in the **Selected value** column.
(>>> 11.4 "Transferring a RoboTeam project to the robot controller" Page 84)

9. Press **Merge** to transfer the changes.
10. Repeat steps 8 to 9 as many times as required. This makes it possible to work through the different areas bit by bit.
When there are no more differences left, the following message is displayed: **No further differences were detected**.
11. Close the **Comparing projects** window.
12. Click on the button **Deploy...** in the menu bar. The overview of the cell assignment is displayed again. The message about the incomplete configuration is no longer displayed.




Fig. 13-7: Overview

13. Click on **Next**. Program generation begins. When the progress indicator bar reaches 100%, the program is generated and the project is transferred.



If a project has been transferred containing an option package that has not yet been installed on the robot controller:
Do not activate the project, i.e. do not continue with the next step! Observe the note about projects with option packages at the beginning of this section!

14. Click on **Activate**.



WARNING In the operating modes AUT and AUT EXT, the project is activated without any request for confirmation if there are only program changes.

15. Only in operating modes T1 and T2: The KUKA smartHMI displays the request for confirmation *Do you want to activate the project [...]?*. In addition, a message is displayed as to whether the activation would overwrite a project, and if so, which.

If no relevant project will be overwritten: Confirm with **Yes** within 30 minutes.

16. An overview is displayed of the changes which will be made in comparison to the project that is still active on the robot controller. The check box **Details** can be used to display details about the changes.



WARNING If changes are listed in the overview under the heading **Safety-relevant communication parameters**, this means that the behavior of the Emergency Stop and “Operator safety” signal may have changed compared with the previous project. After activation of the project, the Emergency Stop and the “Operator safety” signal must be checked for safe functioning. If the project is activated on several robot controllers, this check must be carried out for every robot controller. Failure to carry out this check may result in death to persons, severe physical injuries or considerable damage to property.

17. The overview displays the request for confirmation *Do you want to continue?*. Confirm with **Yes**. The project is activated on the robot controller. A confirmation is displayed in WorkVisual.




Fig. 13-8: Confirmation in WorkVisual

18. Close the **Project deployment** window by selecting **Finish**.
19. If the request for confirmation on the robot controller is not answered within 30 minutes, the project is still transferred, but is not activated on the robot controller. The project can then be activated separately.
(>>> 13.5 "Activating a project" Page 108)

WARNING

After activation of a project on the robot controller, the safety configuration must be checked there! If this is not done, the robot will possibly be operated with incorrect data. Death to persons, severe physical injuries or considerable damage to property may result.

(>>> 13.6 "Checking the safety configuration of the robot controller" Page 110)

WARNING

If the activation of a project fails, an error message is displayed in WorkVisual. In this case, one of the following measures must be carried out:

- Either: Activate a project again (the same one or a different one).
- Or: Reboot the robot controller with a cold restart.

13.5 Activating a project

- A project can be activated on the robot controller from within WorkVisual.
(>>> 13.5.1 "Activating a project (in WorkVisual)" Page 108)
- A project can be activated directly on the robot controller.



Information about activation on the robot controller can be found in the **Operating and Programming Instructions for System Integrators** for the KUKA System Software.

13.5.1 Activating a project (in WorkVisual)

Precondition

- Network connection to the real robot controller
- The real robot controller and the KUKA smartHMI are running.
- The user group "Expert" or higher is selected on the real robot controller.
Restriction: If the activation would cause changes in the area **Safety-relevant communication parameters**, the user group "Safety recovery" or higher must be selected.

- If the operating mode AUT or AUT EXT is selected on the real robot controller: The project can only be activated if this affects only KRL programs. If the project contains settings that would cause other changes, it cannot be activated.



If one of the options KUKA.SafeOperation or KUKA.SafeRangeMonitoring is installed on the robot controller, different user groups may apply. Information can be found in the documentation for these options.



If a project has been transferred containing an option package that has not yet been installed on the robot controller:
Do not activate the project! For such projects, the procedure differs from the usual procedure for transfer and activation. Further information can be found in the section on project deployment.
(>>> 13.4 "Transferring the project to the robot controller" Page 104)

Procedure

1. Select the menu sequence: **File > Browse for project**. The **Project Explorer** is opened. On the left, the **Search** tab is selected.
2. In the **Available cells** area, expand the node of the desired cell. All the robot controllers of this cell are displayed.
3. Expand the node of the desired robot controller. All projects are displayed. The active project is indicated by a small green arrow.
4. Select the desired project and click on the **Activate project** button. The **Project deployment** window is opened.
5. Click on **Next**.



WARNING In the operating modes AUT and AUT EXT, the project is activated without any request for confirmation if there are only program changes.

6. Only in operating modes T1 and T2: The KUKA smartHMI displays the request for confirmation *Do you want to activate the project [...]?*. In addition, a message is displayed as to whether the activation would overwrite a project, and if so, which.
If no relevant project will be overwritten: Confirm with **Yes** within 30 minutes.
7. On the KUKA smartHMI, an overview is displayed of the changes which will be made in comparison to the project that is still active on the robot controller. The check box **Details** can be used to display details about the changes.



WARNING If changes are listed in the overview under the heading **Safety-relevant communication parameters**, this means that the behavior of the Emergency Stop and "Operator safety" signal may have changed compared with the previous project.
After activation of the project, the Emergency Stop and the "Operator safety" signal must be checked for safe functioning. If the project is activated on several robot controllers, this check must be carried out for every robot controller. Failure to carry out this check may result in death to persons, severe physical injuries or considerable damage to property.

8. The overview displays the request for confirmation *Do you want to continue?*. Confirm with **Yes**. The project is activated on the robot controller. A confirmation is displayed in WorkVisual.
9. In WorkVisual, close the **Project deployment** window by selecting **Exit**.
10. Click on **Refresh** in the **Project Explorer**. The active project is now indicated by a small green arrow. (The small green arrow disappears from the project that was active before.)

 **WARNING** After activation of a project on the robot controller, the safety configuration must be checked there! If this is not done, the robot will possibly be operated with incorrect data. Death to persons, severe physical injuries or considerable damage to property may result.
(>>> 13.6 "Checking the safety configuration of the robot controller"
Page 110)

 **WARNING** If the activation of a project fails, an error message is displayed in WorkVisual. In this case, one of the following measures must be carried out:

- Either: Activate a project again (the same one or a different one).
- Or: Reboot the robot controller with a cold restart.

13.6 Checking the safety configuration of the robot controller

Description The safety configuration of the robot controller must be checked in the following cases:

- After activation of a WorkVisual project on the robot controller
- Generally after changes to the machine data (independent of WorkVisual).

 **WARNING** If the safety configuration is not checked and updated where necessary, it may contain incorrect data. Death to persons, severe physical injuries or considerable damage to property may result.

 Information about checking the safety configuration is contained in the Operating and Programming Instructions for System Integrators.

13.7 Transferring a project from the robot controller to WorkVisual

Description On every robot controller to which a network connection is established, a project can be selected and transferred to WorkVisual. This is also possible if this project is not yet present on this PC.

The project is saved in the directory: My Files\WorkVisual Projects\Downloaded Projects.

Precondition

- Network connection to the robot controller
- No external axes have been added or deleted in the project on the robot controller.

Procedure

1. Select the menu sequence: **File > Browse for project**. The **Project Explorer** is opened. On the left, the **Search** tab is selected.
2. In the **Available cells** area, expand the node of the desired cell. All the robot controllers of this cell are displayed.
3. Expand the node of the desired robot controller. All projects are displayed.
4. Select the desired project and click on **Open**. The project is opened in WorkVisual.

13.8 Comparing projects (and accepting differences)

Description A project in WorkVisual can be compared with another project. This can be a project on a robot controller or a locally saved project. The differences are clearly listed. The user can decide for each individual difference whether to

leave the state as in the current project or to transfer the state from the other project.

Precondition

- The project that is to be compared is open in WorkVisual.

If the other project to be compared is located on a robot controller:

- The robot controller is running.
- Network connection to the robot controller

Procedure

1. In WorkVisual, select the menu sequence **Extras > Compare projects**. The **Comparing projects** window is opened.
2. Select the project with which the current WorkVisual project should be compared, e.g. the project of the same name on the real robot controller.




Fig. 13-9: Selecting a project for “Merge”

3. Click on **Next**. A progress bar is displayed. (If the project contains more than one controller, a bar is displayed for each one.)
(>>> "Progress bars" Page 112)
4. When the progress bar is full and the message **Status: Ready for merge** is displayed: Click on **Show differences**. The differences between the projects are displayed in an overview.
(>>> "Comparison" Page 112)
If no differences were determined, this is indicated in the message window. Continue with step 8. After this, no further steps are necessary.
5. For each difference, select which state to accept. This does not have to be done for all the differences at one go.
If suitable, the default selection can also be accepted.
6. Press **Merge** to transfer the changes to WorkVisual.
7. Repeat steps 5 to 6 as many times as required. This makes it possible to work through the different areas bit by bit.
When there are no more differences left, the following message is displayed: **No further differences were detected**.
8. Close the **Comparing projects** window.
9. If parameters of external axes have been changed in the project on the robot controller, these must now be updated in WorkVisual:
 - Open the **Machine data configuration** window for this external axis.
(>>> 6.17 "Adding an external axis" Page 29)
 - In the area **General axis-specific machine data**, click on the button for importing machine data.
The data are updated.
10. Save the project.

Progress bars




Fig. 13-10: Example: progress bar

This view shows all the robot controllers which are contained in the project. A separate bar is displayed for each of these robot controllers. For each bar, the real robot controller to which the project was last transferred is also specified. The check boxes are used to select for which robot controllers the comparison should be carried out.

If additional robot controllers were added or removed in WorkVisual after deployment, these robot controllers are also displayed here. They are marked as invalid, however, and cannot be selected.

Comparison

The differences between the projects are displayed in an overview. For each difference, the user can select which state to accept. The default setting is as follows:

- For all elements that are present in the open project, the state of this project is selected.
- For all elements that are not present in the open project, the state of the comparison project is selected.

 Exception: For projects with a VKRC 4 controller, the state of the comparison project is always selected for the long texts.




Fig. 13-11: Example: overview of differences

Item	Description
1	<p>The node for the robot controller. The various project areas are represented by sub-nodes. The nodes can be expanded to display the comparisons.</p> <p>If several robot controllers are present, these are listed one after the other.</p> <ul style="list-style-type: none"> ■ In each line, place a check mark in the box for the value that should be transferred. ■ A check mark next to Not available means that the element will not be transferred, or that it will be deleted from the project if already present. ■ If a check box is activated for a node, the check boxes for all subordinate elements are also automatically activated. <p>If a check box is deactivated for a node, the check boxes for all subordinated elements are also automatically deactivated.</p> <p>The subordinate elements can also be edited individually, however.</p> <ul style="list-style-type: none"> ■ A filled-in box means: at least one of the subordinate elements is selected, but not all.
2	State of the project that is open in WorkVisual
3	State of the comparison project
4	<p>Back arrow: The focus in the display jumps to the previous difference.</p> <p>Forward arrow: The focus in the display jumps to the next difference.</p> <p>Collapsed nodes are automatically expanded.</p>
5	TRUE: Detailed information is shown for the selected line in the overview.
6	Filter
7	Transfers the selected changes to the open project.

14 Diagnosis

14.1 Trace

Trace recordings are an important diagnostic tool during start-up of the industrial robot and during troubleshooting. They are also used for optimization of the machine data. The trace function can be used to record different variables with the program running, e.g. actual current, setpoint current, states of inputs and outputs, etc. The recording can then be displayed using the oscilloscope.

In WorkVisual it is possible to configure trace recordings and transfer them to the robot controller. The recording can also be started in WorkVisual. In addition, trace configurations can be imported from the robot controller to WorkVisual. The results of trace recordings can also be imported to WorkVisual. The oscilloscope function is also available here for display and evaluation.

14.1.1 Configuring and starting the trace recording

Description	During configuration, the data to be recorded are specified. The robot controller saves the recording in the directory: C:\KRC\ROBOTER\TRACE.
Precondition	<ul style="list-style-type: none"> ■ Online administration workspace
Procedure	<ol style="list-style-type: none"> 1. Select the menu sequence Editors > Trace configuration. The Trace configuration window is opened. 2. Select a configuration or create a new configuration on the General tab. Edit the configuration if required. (>>> 14.1.4 "Trace configuration" window" Page 116) 3. In the Cell view window, select the robot controllers to which the configuration is to be transferred. 4. On the General tab, click on the Save configuration on controller button. 5. Respond to the request for confirmation asking whether the configuration should be activated by pressing Yes. 6. Click on the Start trace button to start the recording. The recording is started in accordance with the defined trigger. Or: Click on Trigger. The recording starts immediately. The State box jumps from #T_END to either #T_WAIT or #TRIGGERED. 7. The recording is ended when the State box displays the value #T_END again.

14.1.2 Importing a trace configuration

Description	Trace configurations can be imported. They are then available under local in the Source box of the Trace configuration window.
Procedure	<ol style="list-style-type: none"> 1. Select the menu sequence File > Import / Export. The Import/Export Wizard window is opened. 2. Select Import / export trace configuration and click on Next. 3. Select the Import option. 4. If the desired directory is not displayed in the Source directory box: Click on Browse and navigate to the directory where the configuration is located. Select the directory and confirm selection with OK. The configurations located in the directory are displayed. 5. Specify whether existing data are to be overwritten.

6. Click on **Finish**.
7. The data are imported. If the import was successful, this is indicated by a message in the **Import/Export Wizard** window. Click on **Close** to close the window.

14.1.3 Exporting a trace configuration

Procedure

1. Select the menu sequence **File > Import / Export**. The **Import/Export Wizard** window is opened.
2. Select **Import / export trace configuration** and click on **Next**.
3. Select the **Export** option. All configurations stored locally are displayed.
4. If the desired directory is not displayed in the **Target directory** box:
Click on **Browse** and navigate to the desired directory. Select the directory and confirm selection with **OK**.
5. Specify whether existing data are to be overwritten.
6. Click on **Finish**.
7. The data are exported. If the export was successful, this is indicated by a message in the **Import/Export Wizard** window. Click on **Close** to close the window.

14.1.4 “Trace configuration” window

14.1.4.1 “General” tab




Fig. 14-1: “General” tab

Item	Description
1	<ul style="list-style-type: none"> ■ local: All the predefined and all the locally saved configurations are available for selection in the Configuration box. ■ [<i>Robot controller</i>]: All the configurations present on this robot controller are available for selection in the Configuration box (in addition to those available under local.) <p>Robot controllers are only displayed in the Source box if they are selected in the Cell view window.</p>
2	A configuration can be selected here. The configuration can be changed.
3	<p>Opens a window in which a name for a new configuration can be entered. If the name is confirmed with Yes, the new configuration is inserted in the list under local.</p> <p>This button is only displayed if the entry local is selected in the Source box.</p>
4	Deletes the configuration displayed in the Configuration box.
5	<p>Activates the configuration displayed in the Configuration box on the robot controllers selected in the Cell view window.</p> <p>If the request for confirmation is answered with No, the configuration is still saved on the robot controller, but is not activated there.</p>
6	Name for the recording. The name can be changed. The robot controller adds extensions to the end of the name, indicating what data have been recorded.
7	Duration of the recording. Only whole numbers can be entered. Maximum value: 9999 s
8	<p>The position of the time phase displayed in the recording relative to the trigger. The % value refers to the duration of the recording.</p> <p>Examples:</p> <ul style="list-style-type: none"> ■ 0%: The displayed time phase starts at the trigger. ■ 30%: 30% of the displayed time phase comes before the trigger, 70% after the trigger. ■ 100%: The displayed time phase ends at the trigger.
All of the following elements are only displayed if a robot controller is selected in the Source box.	
9	Trace configuration that is currently active on the robot controller.
10	<ul style="list-style-type: none"> ■ #T_START: Recording is running. ■ #T_STOP: Recording is not running.
11	<p>State of the recording</p> <ul style="list-style-type: none"> ■ #T_WAIT: The recording is started and is waiting for the trigger. ■ #TRIGGERED: The recording continues for the time defined by the trace length and trigger. ■ #T_END: No recording is running.
12	Starts the recording with the configuration displayed under Trace file . This button is only displayed if no recording has been started yet.

Item	Description
13	Stops the recording. This button is only displayed if a recording has been started.
14	Starts the recording. This button is only displayed if a recording has already been started. Strictly speaking, data are recorded as soon as the Start trace button is pressed. The trigger merely controls which time phase of the recording is then displayed in the trace files.

14.1.4.2 “Trigger” tab

Triggers can be selected here. Triggers control when data is recorded.

Strictly speaking, data are recorded as soon as the **Start trace** button is pressed. The trigger merely controls which time phase of the recording is then displayed in the trace files.




Fig. 14-2: “Trigger” tab

Item	Description
1	A module can be selected here. The modules contain numerous predefined triggers.
2	This box is only displayed if the selected module refers to the robot axes. It allows selection of whether the triggers should refer to all axes or to a particular axis.
3	All the triggers for this module are displayed here. RIGHT ARROW copies triggers selected here to the Selected trigger box. (Alternatively: double-click on a trigger.)

Item	Description
4	Depending on the entry selected under available triggers , filters are available here for this entry.
5	Here the triggers are inserted that are to be used for the current configuration. LEFT ARROW removes the triggers selected here. (Alternatively: double-click on a trigger.) DOUBLE LEFT ARROW clears this box.

14.1.4.3 “I/O” tab

Here you can select which inputs or outputs are to be recorded.




Fig. 14-3: “I/O” tab

Item	Description
1	All the available inputs/outputs are displayed here.
2	Here a number range can be specified from the entry selected under Available channels .
3	Select the desired recording rate.

Item	Description
4	<p>Here the inputs/outputs are inserted that are to be recorded with the current configuration.</p> <p>RIGHT ARROW transfers all the inputs/outputs selected via Available channels and From ID [...] to ID [...] to this box. LEFT ARROW removes the inputs/outputs selected here. (Alternative to these arrow keys: double-click on a channel.)</p> <p>DOUBLE LEFT ARROW clears this box.</p>
5	<p>Group combines all channels of the same type and with consecutive numbers into a single entry. This gives greater clarity to the display. It has no effect on the recording.</p> <p>Ungroup undoes the grouping.</p>

14.1.4.4 “Channels” tab




Fig. 14-4: “Channels” tab

Item	Description
1	A module can be selected here. The modules contain different channels.
2	This box is only displayed if the selected module refers to the robot axes. It allows selection of whether the channels should refer to all axes or to a particular axis.
3	All the channels for the selected module are displayed here.

Item	Description
4	<p>Here the channels are inserted that are to be recorded with the current configuration.</p> <p>RIGHT ARROW transfers all the entries selected under Available channels to this box. LEFT ARROW removes the entries selected here. (Alternative to these arrow keys: double-click on an entry.)</p> <p>DOUBLE LEFT ARROW clears this box.</p>
5	Select the desired recording rate.

14.1.5 Importing a trace recording

Description To be able to display a trace recording in WorkVisual, it must first be imported.

Precondition ■ The recording was created with KSS (or VSS) 8.2 or 8.1 or 5.4.

Procedure

1. Select the menu sequence **File > Import / Export**. The **Import/Export Wizard** window is opened.
2. Select **Import trace results** and click on **Next**.
3. Click on **Browse** and navigate to the directory where the results are located. Select the directory and confirm selection with **OK**.
The trace files located in the directory are displayed.
4. Specify whether existing data are to be overwritten.
5. In the **Format** box, select the entry **(V)KRC 8.1 / 8.2 / 5.4**.
6. Click on **Finish**.
7. The data are imported. If the import was successful, this is indicated by a message in the **Import/Export Wizard** window. Click on **Close** to close the window.

14.1.6 Displaying a trace recording

Precondition

- **Online administration** workspace
- The recording has been imported to WorkVisual.
(>>> 14.1.5 "Importing a trace recording" Page 121)

Procedure

1. Select the menu sequence **Editors > Trace Analysis (Oscilloscope)**. The **Trace Analysis (Oscilloscope)** window is opened.
2. On the **Channels** tab, select a recording.
(>>> 14.1.7.1 "'Channels" tab" Page 122)
3. Select the channels to be displayed.
4. The channels are displayed on the **Oscilloscope** tab. Adapt the display, if necessary. (E.g. zoom or change the colors of the traces.)
(>>> 14.1.7.2 "'Oscilloscope" tab" Page 123)

14.1.7 “Trace Analysis” window

14.1.7.1 “Channels” tab




Fig. 14-5: “Channels” tab

Item	Description
1	<ul style="list-style-type: none"> ■ local: All the locally saved recordings are available for selection in the Trace recording box. ■ [<i>Robot controller</i>]: All the recordings present on this robot controller are available for selection in the Trace recording box (in addition to those available under local.) <p>Robot controllers are only displayed in the Source box if they are selected in the Cell view window.</p>
2	A recording can be selected here.
3	Detailed information regarding the selected recording is displayed here.
4	Deletes the recording selected in the Trace recording box.

Item	Description
5	All the channels contained in the selected recording are displayed here.
6	Here the channels are inserted that are to be displayed in the oscilloscope. It is possible to insert entries from different recordings in this box. RIGHT ARROW moves all the entries selected under Available channels to this box. LEFT ARROW removes the entries selected here. (Alternative to these arrow keys: double-click on the entry.) DOUBLE LEFT ARROW clears this box.

14.1.7.2 "Oscilloscope" tab




Fig. 14-6: "Oscilloscope" tab

Check box	Description
Show legend	Activated: The diagram displays which channel name belongs to which trace color.
Display cursor coordinates	Activated: The X and Y coordinates of the mouse pointer position are displayed in the diagram.

Column	Description
Active	Activated: The curve is displayed in the oscilloscope. Deactivated: The curve is displayed in the oscilloscope.
Trace name	Name of trace
Module name	Name of the module
Channel name	Name of channel
Unit	Unit for the Y axis of the oscilloscope display (can be different for each curve)
Thickness	Line thickness of the curve (unit: point)
Scaling	This selection box allows the amplitude to be increased or decreased in steps. In this way, it is also possible to make curves more visible which only have a low amplitude or which are hidden by other curves.
Color	Color of the curve
Points	Activated: The motion blocks of the robot are displayed. Start and end are shown for each block.
Values	Activated: The individual values which make up the curve are displayed as points.
RMS	Activated: The RMS value is shown. Note: The RMS value refers to the phase of the recording represented in the oscilloscope. In electrical engineering, the RMS value is the root-mean-square value of a signal that changes over time. RMS = Root Mean Square
Steps	Activated: The curve runs horizontally on the X plane from one value until it reaches the Y value of the next value. From there it runs vertically up to this Y value. Deactivated: The curve takes the shortest path from one value to the next.

14.1.8 Panning and zooming the oscilloscope display

Procedure

Panning:

1. Click in the display and hold down the mouse button.
2. Drag with the mouse. The display moves with the mouse.

Zooming:

1. Click into the display.
2. Scroll with the mouse wheel.
Scroll down: Zoom gets smaller. Scroll up: Zoom gets larger.

Enlarging a section:

1. Hold down the SHIFT key.
2. Click in the display and hold down the mouse button.
3. Move the mouse over the desired section. A gray rectangle is displayed. The size can be changed by moving the mouse. (The aspect ratio cannot be changed.)

4. Release the mouse button. The contents of the gray rectangle are displayed in enlarged form.

In this procedure, the aspect ratio of the selected section is adapted to the oscilloscope display:

1. Hold down the CTRL key.
2. Click in the display and hold down the mouse button.
3. Move the mouse over the desired section. A gray rectangle is displayed. The size and the aspect ratio can be changed by moving the mouse.
4. Release the mouse button. The contents of the gray rectangle are displayed in enlarged form.

Restoring the default view:

1. Right-click in the display.
2. Select **Fit to view** from the context menu.

14.1.9 Creating a screenshot of the oscilloscope display

Procedure **Creating a screenshot in the clipboard:**

1. Right-click in the display.
2. Select **Copy screenshot** from the context menu.

Creating and saving the screenshot:

1. Right-click in the display.
2. Select **Save screenshot** from the context menu. A window opens in which the target directory can be selected. The screenshot is saved there as a PNG file.

14.2 Displaying diagnostic data about the robot controller

Description The diagnostic functionality makes it possible to display a wide range of diagnostic data concerning numerous software modules of a robot controller. The parameters displayed depend on the selected module. The display includes states, fault counters, message counters, etc.

Examples of modules:

- **Kcp3 driver** (= drive for the smartPAD)
- Network driver

“Lamps” indicate the status of the parameters, etc.:

- **Green:** Status OK
- **Yellow:** Status critical, could be faulty
- **Red:** Fault

Precondition

- Network connection to the robot controller
- The robot controller and the KUKA smartHMI are running.
- **Online administration** workspace

Procedure

1. Select the desired robot controller in the **Cell view** window. It is also possible to select more than one.
2. Select the menu sequence **Editors > Diagnostic monitor**. The **Diagnostic monitor** window is opened.
3. An entry is displayed for each robot controller selected. Expand the entry for one robot controller.
4. Select a module in the module overview. Diagnostic data are displayed for the selected module.




Fig. 14-7: Diagnostic monitor window (section)

Item	Description
1	Expand/collapse entry for the robot controller
2	Name of the active project on the robot controller While the connection to the robot controller is being established, a lamp flashes next to the name. It disappears when the connection is established.
3	This lamp indicates the status of the robot controller: <ul style="list-style-type: none"> ■ Red: When the status of at least one module is red. ■ Yellow: When the status of at least one module is yellow and no module is red. ■ Green: When the status of all modules is green. Flashing green: Attempting to establish a connection to the robot controller.
4	Graphical representation of the topology for the following bus topologies: <ul style="list-style-type: none"> ■ Controller bus ■ KUKA Operator Panel Interface The lamp on a device is gray if the device is not connected to the real robot controller.

Item	Description
5	<p>Module overview</p> <p>Lamps indicate the status of the modules:</p> <ul style="list-style-type: none"> ■ Red: When the status of at least one parameter is red. ■ Yellow: When the status of at least one parameter is yellow and no parameter is red. ■ Green: When the status of all parameters is green.
6	<p>Diagnostic data about the selected module</p> <p>Lamps indicate the status of the parameters:</p> <ul style="list-style-type: none"> ■ Red: If the value lies outside of the range defined in the red box in the Limit values column. ■ Yellow: If the value lies outside of the range defined in the yellow box in the Limit values column. ■ Green: If the value lies within the range defined in the yellow box in the Limit values column.

Diagnostic data:

Column	Description
Name	Diagnosed parameter
Value	Current value of the diagnosed parameter
Extreme values	<ul style="list-style-type: none"> ■ Upper value: Greatest diagnosed value since the Diagnosis window was opened ■ Lower value: Smallest diagnosed value since the Diagnosis window was opened
Unit	If there is a unit associated with a parameter, this is displayed here. In some cases, the units can be changed (e.g. from seconds to milliseconds).
Graph over time	Change of the value over time
Limit values	<p>This column partly contains default values. The values can be changed/specified by the user.</p> <p>Yellow box:</p> <ul style="list-style-type: none"> ■ Upper value: If this value is exceeded, the parameter is marked yellow. ■ Lower value: If the current value falls below this value, the parameter is marked yellow. <p>Red box:</p> <ul style="list-style-type: none"> ■ Upper value: If this value is exceeded, the parameter is marked red. ■ Lower value: If the current value falls below this value, the parameter is marked red.

14.3 Displaying online system information

Precondition ■ **Online administration** workspace

Procedure

1. Select the desired robot controller in the **Cell view** window. It is also possible to select more than one.
2. Select the menu sequence **Editors > System information editor**. The **System information editor** window is opened. An entry is displayed for each robot controller selected.

Description




Fig. 14-8: "System information editor" window

Column	Description
Controller Info	Information about the robot controller is displayed here.
Robot info	Information about the robot is displayed here.
Controller status	Shows the status of the Submit interpreter and robot interpreter and the operating mode. The status displays correspond to the status displays on the KUKA smartHMI. Information about this can be found in the operating and programming instructions for the KUKA System Software (KSS).
Project Info	Information about the active project is displayed here.
Commands	Edit: Opens the Device properties window. Create archive: Opens the Generate archives window. (The data for this robot controller can be archived.)

Button	Description
Archive all	Create archive: Opens the Generate archives window. (The data for all robot controllers selected in the Cell view window can be archived.)

Device properties window:




Fig. 14-9: "Device properties" window

Item	Description
1	The name of the robot controller can be changed here.
2	The name of the robot can be changed here.

Item	Description
3	A description can be entered here for information purposes. The description is displayed in the following places in the Project deployment window: <ul style="list-style-type: none"> ■ In the Information area ■ During activation in the lower window with the progress bar
4	Activated: If OK is pressed, the RDC data are transferred to the RDC memory from D:\BackupAll.zip.

Generate archives window:



Fig. 14-10: “Generate archives” window

Item	Description
1	The name of the robot controller is displayed here. If the window was opened via the Archive all button, the window displays all the robot controllers that are selected in the Cell view window.
2	Activated: The log data are also archived. Deactivated: The log data are not archived.
3	A target directory for the archive can be selected here. A ZIP file is generated as an archive for each robot controller. The name of ZIP file always contains the name of the robot and the robot controller.

15 KUKA Service

15.1 Requesting support

Introduction The KUKA Roboter GmbH documentation offers information on operation and provides assistance with troubleshooting. For further assistance, please contact your local KUKA subsidiary.

Information The following information is required for processing a support request:

- Model and serial number of the robot
- Model and serial number of the controller
- Model and serial number of the linear unit (if applicable)
- Version of the KUKA System Software
- Optional software or modifications
- Archive of the software
- Application used
- Any external axes used
- Description of the problem, duration and frequency of the fault

15.2 KUKA Customer Support

Availability KUKA Customer Support is available in many countries. Please do not hesitate to contact us if you have any questions.

Argentina Ruben Costantini S.A. (Agency)
Luis Angel Huergo 13 20
Parque Industrial
2400 San Francisco (CBA)
Argentina
Tel. +54 3564 421033
Fax +54 3564 428877
ventas@costantini-sa.com

Australia Headland Machinery Pty. Ltd.
Victoria (Head Office & Showroom)
95 Highbury Road
Burwood
Victoria 31 25
Australia
Tel. +61 3 9244-3500
Fax +61 3 9244-3501
vic@headland.com.au
www.headland.com.au

Belgium	KUKA Automatisering + Robots N.V. Centrum Zuid 1031 3530 Houthalen Belgium Tel. +32 11 516160 Fax +32 11 526794 info@kuka.be www.kuka.be
Brazil	KUKA Roboter do Brasil Ltda. Avenida Franz Liszt, 80 Parque Novo Mundo Jd. Guançã CEP 02151 900 São Paulo SP Brazil Tel. +55 11 69844900 Fax +55 11 62017883 info@kuka-roboter.com.br
Chile	Robotec S.A. (Agency) Santiago de Chile Chile Tel. +56 2 331-5951 Fax +56 2 331-5952 robotec@robotec.cl www.robotec.cl
China	KUKA Automation Equipment (Shanghai) Co., Ltd. Songjiang Industrial Zone No. 388 Minshen Road 201612 Shanghai China Tel. +86 21 6787-1808 Fax +86 21 6787-1805 info@kuka-sha.com.cn www.kuka.cn
Germany	KUKA Roboter GmbH Zugspitzstr. 140 86165 Augsburg Germany Tel. +49 821 797-4000 Fax +49 821 797-1616 info@kuka-roboter.de www.kuka-roboter.de

France	KUKA Automatismes + Robotique SAS Techvallée 6, Avenue du Parc 91140 Villebon S/Yvette France Tel. +33 1 6931660-0 Fax +33 1 6931660-1 commercial@kuka.fr www.kuka.fr
India	KUKA Robotics India Pvt. Ltd. Office Number-7, German Centre, Level 12, Building No. - 9B DLF Cyber City Phase III 122 002 Gurgaon Haryana India Tel. +91 124 4635774 Fax +91 124 4635773 info@kuka.in www.kuka.in
Italy	KUKA Roboter Italia S.p.A. Via Pavia 9/a - int.6 10098 Rivoli (TO) Italy Tel. +39 011 959-5013 Fax +39 011 959-5141 kuka@kuka.it www.kuka.it
Japan	KUKA Robotics Japan K.K. Daiba Garden City Building 1F 2-3-5 Daiba, Minato-ku Tokyo 135-0091 Japan Tel. +81 3 6380-7311 Fax +81 3 6380-7312 info@kuka.co.jp
Korea	KUKA Robotics Korea Co. Ltd. RIT Center 306, Gyeonggi Technopark 1271-11 Sa 3-dong, Sangnok-gu Ansan City, Gyeonggi Do 426-901 Korea Tel. +82 31 501-1451 Fax +82 31 501-1461 info@kukakorea.com

Malaysia	KUKA Robot Automation Sdn Bhd South East Asia Regional Office No. 24, Jalan TPP 1/10 Taman Industri Puchong 47100 Puchong Selangor Malaysia Tel. +60 3 8061-0613 or -0614 Fax +60 3 8061-7386 info@kuka.com.my
Mexico	KUKA de Mexico S. de R.L. de C.V. Rio San Joaquin #339, Local 5 Colonia Pensil Sur C.P. 11490 Mexico D.F. Mexico Tel. +52 55 5203-8407 Fax +52 55 5203-8148 info@kuka.com.mx
Norway	KUKA Sveiseanlegg + Roboter Sentrumsvegen 5 2867 Hov Norway Tel. +47 61 18 91 30 Fax +47 61 18 62 00 info@kuka.no
Austria	KUKA Roboter Austria GmbH Vertriebsbüro Österreich Regensburger Strasse 9/1 4020 Linz Austria Tel. +43 732 784752 Fax +43 732 793880 office@kuka-roboter.at www.kuka-roboter.at
Poland	KUKA Roboter Austria GmbH Spółka z ograniczoną odpowiedzialnością Oddział w Polsce Ul. Porcelanowa 10 40-246 Katowice Poland Tel. +48 327 30 32 13 or -14 Fax +48 327 30 32 26 ServicePL@kuka-roboter.de

Portugal KUKA Sistemas de Automatización S.A.
Rua do Alto da Guerra n° 50
Armazém 04
2910 011 Setúbal
Portugal
Tel. +351 265 729780
Fax +351 265 729782
kuka@mail.telepac.pt

Russia OOO KUKA Robotics Rus
Webnaja ul. 8A
107143 Moskau
Russia
Tel. +7 495 781-31-20
Fax +7 495 781-31-19
kuka-robotics.ru

Sweden KUKA Svetsanläggningar + Robotar AB
A. Odhners gata 15
421 30 Västra Frölunda
Sweden
Tel. +46 31 7266-200
Fax +46 31 7266-201
info@kuka.se

Switzerland KUKA Roboter Schweiz AG
Industriestr. 9
5432 Neuenhof
Switzerland
Tel. +41 44 74490-90
Fax +41 44 74490-91
info@kuka-roboter.ch
www.kuka-roboter.ch

Spain KUKA Robots IBÉRICA, S.A.
Pol. Industrial
Torrent de la Pastera
Carrer del Bages s/n
08800 Vilanova i la Geltrú (Barcelona)
Spain
Tel. +34 93 8142-353
Fax +34 93 8142-950
Comercial@kuka-e.com
www.kuka-e.com

South Africa	Jendamark Automation LTD (Agency) 76a York Road North End 6000 Port Elizabeth South Africa Tel. +27 41 391 4700 Fax +27 41 373 3869 www.jendamark.co.za
Taiwan	KUKA Robot Automation Taiwan Co., Ltd. No. 249 Pujong Road Jungli City, Taoyuan County 320 Taiwan, R. O. C. Tel. +886 3 4331988 Fax +886 3 4331948 info@kuka.com.tw www.kuka.com.tw
Thailand	KUKA Robot Automation (M)SdnBhd Thailand Office c/o Maccall System Co. Ltd. 49/9-10 Soi Kingkaew 30 Kingkaew Road Tt. Rachatheva, A. Bangpli Samutprakarn 10540 Thailand Tel. +66 2 7502737 Fax +66 2 6612355 atika@ji-net.com www.kuka-roboter.de
Czech Republic	KUKA Roboter Austria GmbH Organisation Tschechien und Slowakei Sezemická 2757/2 193 00 Praha Horní Počernice Czech Republic Tel. +420 22 62 12 27 2 Fax +420 22 62 12 27 0 support@kuka.cz
Hungary	KUKA Robotics Hungaria Kft. Fő út 140 2335 Taksony Hungary Tel. +36 24 501609 Fax +36 24 477031 info@kuka-robotics.hu

USA KUKA Robotics Corp.
22500 Key Drive
Clinton Township
48036
Michigan
USA
Tel. +1 866 8735852
Fax +1 586 5692087
info@kukarobotics.com
www.kukarobotics.com

UK KUKA Automation + Robotics
Hereward Rise
Halesowen
B62 8AN
UK
Tel. +44 121 585-0800
Fax +44 121 585-0900
sales@kuka.co.uk

Index

A

Add, robot 28
 Adding, device 33
 Adding, external axis 29
 Anchor cross 16, 17
 Anchor points 16
 Auto-complete 92

B

Bus configuration 45
 Bus I/Os, mapping 55
 Bus Scan 49
 Button bar 19
 Button bars 15
 Buttons, displaying/hiding 18

C

Catalog Scan 26
 Catalog, inserting 26
 Catalog, removing 27
 Catalogs (window) 26
 Close, project 25
 Close, WorkVisual 25
 Code generation 101
 Communication parameters, safety-relevant 39
 Configuration, devices 46
 Configuration, field bus master 46
 Controller bus 68, 70
 Copy, project 25

D

Data format 52
 Devices, adding 46
 Devices, configuration 46
 Devices, inserting into bus 49
 Diagnosis 115
 DTM 8

E

Editing, long texts 63
 Export, bus configuration 61
 Export, long texts 64
 Export, safety configuration 41
 Export, subproject 34
 Exporting, trace configuration 116
 External axes 29, 110

F

Fast entry, KRL 93
 Field bus master, add 45
 Field bus master, configuration 46
 Filtering, signals 56
 Folds 94

G

Graphical user interface 15
 Graphical user interface, overview 15
 Graphics card 13

Grouping, signals 60

H

Help 15

I

ID, project 24
 Import, long texts 63
 Import, safety configuration 41
 Import, safety zones 42
 Importing, machine data 40
 Importing, PROFINET configuration 47
 Importing, trace configuration 115
 Importing, trace recording 121
 Insertion, devices into bus 49
 Installation 13
 Installation, WorkVisual 13
 Intel, data format 52
 Introduction 7
 IO Mapping (window) 55, 56
 IP addresses 46, 47

K

KCP 8
 Keyboard shortcuts 35
 KRL 8
 KRL Editor 89
 KRL Editor, Folds 94
 KRL Editor, opening 89
 KSS 8
 KUKA Customer Support 131
 KUKA smartHMI 8
 KUKA smartPAD 8
 KUKA.OptionPackageEditor 34

L

Language, changing 36
 Licenses 7
 Long texts 63

M

Mapping, inputs/outputs 57
 Menu bar 15
 Messages (window) 16, 21
 Motion master 80
 Motorola, data format 52
 Multiprog 13, 56

O

Open source 7
 Operation 23
 Operator safety acknowledgement 40
 OptionPackageEditor 34
 Oscilloscope 115
 Overview, graphical user interface 15

P

Peripheral contactor 40

- Pinning 101
- Printing, I/O connections 36
- Printing, long texts 36
- Printing, safety configuration 36
- Processor 13
- Product description 9
- Programming 87
- Project Explorer 23
- Project information, saving 24
- Project structure (window) 15, 21
- Project, new 24
- Project, open 23
- Project, saving 25
- Properties (window) 16

R

- RAM 13
- Required knowledge and skills 7
- Robot controller, add 27
- Robot controller, removing 28
- RoboTeam 75

S

- Safety 11
- Safety configuration 39
- Safety configuration, components 39
- Safety configuration, local 39
- Safety instructions 7
- Safety master 78
- Scan, bus 49
- Searching, signals 59
- Service, KUKA Roboter 131
- Setting to active, robot controller 27
- Setting to inactive, robot controller 27
- smartHMI 8
- smartPAD 8
- Snippets 93
- Snippets, user-specific 96
- Starting, WorkVisual 23
- Subproject 34
- Support request 131
- System requirements, PC 13
- System requirements, robot controller 13
- System requirements, software 13

T

- Target group 7
- Template, for project 24
- Template, for RoboTeam 75
- Terms used 8
- Time master 79
- Trace 115
- Trace, configuration 115
- Trace, displaying data 121
- Trace, starting 115
- Trace, state 117
- Training 7
- Transferring the project to the robot controller 104

U

- Uninstallation, WorkVisual 14

V

- View (menu item) 18

W

- Wagon driver 72
- Warnings 7
- Windows, displaying/hiding 16
- Windows, repositioning 16
- Workspace master 82
- Workspace Selection (window) 16, 18
- Workspaces, RoboTeam 82
- WVPS 34
- WVS 25

